

Balluff IO-Link Profinet Setup Guide

PN Configurator/PLC/HMI

Version

2.02



Content

1	Overview	1
1.1	Overview of the Balluff IOL Profinet Setup Guide.....	1
1.2	Example of System Configuration	2
1.3	Software and Project Requirements	4
1.3.1	Programming Software Requirements.....	4
1.4	Importing User Libraries.....	5
2	GX Configurator PN Profinet Setup.....	8
2.1	Creating a new ProfiNet Configuration	8
2.2	ProfiNet CPU (ME1PN1FW-Q) Setup.....	10
2.3	Importing GSDML file to GX Configurator PN	12
2.4	ProfiNet Node Initial Device Setup.....	13
2.5	ProfiNet Node Device General Configuration	17
2.6	ProfiNet Node Device Module Configuration-Port Functions.....	19
2.7	ProfiNet Node Device Module Configuration-IO-Link/Standard I/O Slot Data	21
2.8	ProfiNet Node Device Module Configuration-Node Diagnostics Slot Data.....	24
2.9	ProfiNet and Main PLC Settings-CPU Project Association and Update Parameters	26
2.10	Saving and Downloading Configuration to PN Controller.....	29
2.11	Referencing I/O/Diagnostic Data Mapping.....	30
3	GX Works 2 PLC Setup.....	34
3.1	PLC Parameters and required Programming.....	35
3.1.1	Configuration of MELPT_APP_ProfinetDiag	37
3.1.2	Necessary System Labels	51
3.2	IO-Link device configuration function blocks.....	52

3.2.1	FB Inputs	53
3.2.2	FB Outputs	54
3.3	IO-Link Master Configuration	55
3.3.1	FB Inputs	56
3.3.2	FB Outputs	57
3.3.3	Program Flow.....	58
3.4	IO-Link Diagnostics required programming.....	59
3.4.1	IOLDiag_PN_module_Lookup	59
3.4.2	IOLDiag_HMI	62
3.5	IO-Link Device Process Data Function Blocks	65
3.5.1	Balluff Pressure Switch: Balluff_PSW_Processdata	65
3.5.2	Balluff_Smartlight_ProcessData	70
3.5.3	Balluff_BNI0041_ProcessData	77
3.5.4	Balluff_BNI0042_ProcessData	79
3.5.5	Balluff_AnalogOut_ProcessData.....	81
3.5.6	Balluff_Ultrasonic_ProcessData	83
3.5.7	Balluff_BAW002F_ProcessData	85
3.5.8	Balluff_BIP0004_ProcessData.....	87
3.5.9	Balluff_BOD0012_ProcessData.....	89
3.5.10	Balluff_Valve16_ProcessData	91
3.5.11	Balluff_Valve24_ProcessData	92
3.6	RFIDIF_Balluff_IOLink_256b / RFIDIF_BalluffBIS_V_M_2K	94
3.6.1	MELPT_APP_RFIDGOT	108
4	GTDesigner 3 HMI Elements	117
4.1.1	ProfiNet Diagnostic Displays.....	118

4.1.2	IO-Link Diagnostics.....	131
4.1.3	IO-Link Maintenance – Device Parameters Setup Display.....	133
4.1.4	IO-Link Pressure Switch Devices.....	135
4.1.5	RFID Editing Screen.....	138

Document Management Information

Date	Version No.	Document Name	Revision	Revised By
8/27/2015	1			MEAU-EG
10/1/2015	1.01			MEAU-EG
1/11/2016	1.02			MEAU-EG
1/28/2016	1.03			MEAU-EG
6/27/2016	2.00		Additional devices, more process data FB and feature add to previous revisions	MEAU-EG
7/25/2016	2.01		Ultrasonic Device Type Error Corrected	MEAU-EG
8/10/2016	2.02		BNI0041 Scaling and RFID FB corrections	MEAU-EG

1 OVERVIEW

1.1 Overview of the Balluff IOL Profinet Setup Guide


This guide shows a user how to setup the IOLink_Diag_PN Template Project for proper use of Balluff IO-link diagnostics, parameterization of IO-link devices, and formatting of the process data from Balluff IO-link devices.

This guide is divided into four main areas:

1. **Overview:** this section which gives general feeling for the software requirements and software package.
2. **Configurator PN Setup:** For proper Profinet/IO-Link configuration/reference of the Profinet CPU.
3. **GXWorks2 FB Setup:** For customization of the Profinet/IO-Link function blocks (FB) in the GXWorks 2 template project.
4. **GTDesigner3 Elements:** Description of Profinet/IO-Link HMI display screens and proper usage and element readouts.

1.2 Example of System Configuration

For Q series, the following configuration is used:



No.	Module	Description
1	Q series programmable controller	Use the base unit, power supply module, and Q series Built-in Ethernet port CPU module.
2	Q12DCCPU-V	Secondary Network CPU configured for Profinet (ME1PN1FW-Q)
3	Ethernet Switch	Switch for all Ethernet/Profinet communications (may be separated into multiple switches if needed)
4	ProfiNet Node Device without IOL	Balluff Profinet Node with NO IOL communication capability

Balluff IO-Link Profinet – Setup Guide

5	ProfiNet Node Device with IOL	Balluff Profinet Node with IOL communication capability
6	IOL Device	Balluff IO-Link Device
7	GOT 2000	HMI interface

1.3 Software and Project Requirements

1.3.1 Programming Software Requirements

To properly open, configure, edit and save project data for IO-Link diagnostics, the required software with minimum revision level is listed below:

Software Title	Version	Description
MELSOFT Navigator	2.12	Integrated project for storing and configuring both the PLC and HMI projects. System labels are used to allow common labels between PLC and HMI with this software. IO-Link indicators on the HMI use system labels extensively.
GX Works2	1.540	PLC software needed for all PLC-related programming. Used in conjunction with MELSOFT Navigator. Numerous FBs require configuration for IO-Link Diagnostics to work properly.
GT Designer3 (GOT 1000 version)	1.151	HMI software needed for all GOT-related programming. Used in conjunction with MELSOFT Navigator. IO-Link diagnostics and Parameter read/write screens reside here.
GX Configurator PN	1.03+	Profinet configuration software to set up all Profinet devices on a network. Used in conjunction with GX Works 2 to map I/O and diagnostic data to/from PLC. Specific IO-Link mapping and Profinet Node master device mapping is needed for proper diagnostics display.


1.4 Importing User Libraries

This section explains how to import any User Library into GX Works2.

There are six key libraries for this project


1. PN_IOLDiag_v200
 - a. This library contains structures and function blocks for IO-Link Diagnostics and maintenance
2. Balluff_IOL_CFG_V201
 - a. This library contains structures and function blocks related to the configuration of Balluff hardware
3. Balluff_IOL_ProcessData_v202
 - a. This library contains structures and function blocks related to utilizing process data for connected IOL Devices
4. RFID_Balluff_BIS_v303
 - a. This library contains structure and FB in regards to RFID access for the BIS-M, BIS-V, and IO-Link RFID
5. Profinet_IO_ME1PN1FW_Q
 - a. This library is necessary and installed by GX Configurator-PN, it maintains data structures of PN controller level data needed by function blocks accessing the Profinet network
6. PN_accessory_v120
 - a. This library contains Acyclic Profinet functions and IO-Link Device Call

- 1) Click on the “User Library” tab on the GX Works 2 Navigation Pane.
- 2) Click the arrow part of this icon, to bring a drop-down menu. Select the “Install” option:




Balluff IO-Link Profinet – Setup Guide

- 3) From the “Import Library to Project” window, click the Browse button, find the .sul library file, and click Open:



- 4) Click the “OK” button. Click “OK” again when prompted that the library has been installed.

The library elements will now show up as a directory tree in the Navigation Pane. Right click on the top folder and select “Open” to view/edit the library elements:





2 GX CONFIGURATOR PN PROFINET SETUP

GX Configurator PN is used to set up the Profinet network configuration in the Q12DCCPU-V CPU module. This section will explain how to set up a new configuration and populate the network with one ProfiNet node device with IO-Link capability. It will also show how to configure all the necessary diagnostic and process data needed for each node and IO-Link device.


Important! Before any configuration can be done on a Profinet node device, a GSDML file specific to that device must be imported into the GX Configurator PN software. GSDML files for target Balluff Profinet devices can be found on the Balluff website (<http://www.balluff.com>)

2.1 Creating a new ProfiNet Configuration

1. Open **GX Configurator PN** and select **File>Configuration Manager** from the top menu. (also the  icon may be pressed on the icon toolbar)
2. From the **Configuration Manager** window, click the **New** button
3. From the **New Configuration** window, Type in a name in the **Configuration:** textbox (optionally, the **Description:** textbox can be also used to further describe the configuration file):



4. Click the **OK** button.
5. Back on the **Configuration Manager** screen, the new project should be listed on the **Available Configurations** table. Be sure the new project is selected and click the **OK** button. (see next page):




This makes the selected project the active one on the main window


You can also restore an included .mit file for a sample configuration

2.2 Profinet CPU (ME1PN1FW-Q) Setup


1. From the **Configuration Manager** window, double-click on the **ME1PN1FW-Q Configuration** entry under the **Description** Item:



2. On the **Add New ME1PN1FW-Q** windows, be sure the Automatic tab is selected for **Detected ME1PN1FW-Q** and click the **Detect** button:




NOTE: Be sure the **Board Name:** is the target Network interface on your computer and that it is connected to the same network as the **ME1PN1FW-Q** module. Check Ethernet connections and IP settings if Automatic detection does not work.

- When the **ME1PN1FW-Q** module is found, click the OK button to close the window.
- Click the Save button ()

2.3 Importing GSDML file to GX Configurator PN

1. Open **GX Configurator PN** and select Library>Add from the top menu :




2. From the GSDML Management window, click the **Next >** button
3. The next screens allow either a single GSDML file or a folder with multiple GSDML files to be imported. Choose the appropriate option, and then click the Browse button to locate the file or folder.
4. Click the **Next >** button twice until the Action is Completed window appears.
5. Click the **Finish** button
6. **Target node should now be configurable in the GX Configurator PN software**


2.4 Profinet Node Initial Device Setup


Use this procedure for setting up the newly-added Profinet node devices when online with the PN CPU module.

You must have the target node device connected to the same network as your PC and PN CPU module.

1. From the Main window, select the **Network Detection** tab:



2. Right click on the **Network** item and select **Online Action** or click the () icon.
3. On the **Devices on the Network** window, the software will scan the Profinet network and show all found nodes on the network (allow a few scans so devices have a chance to respond):



4. Once the target device appears on the list, uncheck the Scanning checkbox. This will allow re-configuration of the target device. Click on the target device from the list.
5. With the target node still selected, adjust settings for Name, IP Address, Sub-Network Mask, and Gateway IP Address as required by your ProfiNet control network. See below for further instructions:

Balluff IO-Link Profinet – Setup Guide

The screenshot shows the 'Devices on the Network' configuration window. At the top, a table lists the network nodes. Below the table, there are sections for 'Scanning', 'Addressing', and 'Name'. Callouts provide instructions for various fields:

- Input these settings based on your network configuration:** Points to the 'Addressing Mode' (DCP), 'DHCP Based on' (MAC Address), 'IP Address' (192.168.1.20), and 'Sub-Netmask' (255.255.255.0).
- Check "Permanent name" to insure name remains changed even after device power Cycle:** Points to the 'Permanent' checkbox under the 'Name' section.
- Set the device name. This must match the name used for setting up the node slot parameters:** Points to the 'Name' field (iolink001).
- Check "Permanent" to insure settings remain changed even after device power cycle:** Points to the 'Permanent' checkbox under the 'Request Status' section.

Name	IP Address	Type	MAC Address	Addressing Mode
iolink001	192.168.001.020	BNI PNT-508-105-Z015	00:19:31:31:2A:B8	DCP

Number of Nodes on the Network: 1

MAC Address: 00:19:31:31:2A:B8
Device Type: BNI PNT-508-105-Z015
Factory Reset

Name: iolink001
Permanent Name ☒ Apply Name


GSDML Presence: The GSDML file corresponding is present in the library.

Addressing
Addressing Mode: DCP
DHCP Based on: MAC Address
Client Identifier:
IP Address: 192 . 168 . 1 . 20
Sub-Netmask: 255 . 255 . 255 . 0
Gateway IP Address: 0 . 0 . 0 . 0
Permanent ☒ Apply

Request Status

- After settings are adjusted, be sure to click **Apply** and **Apply Name** button to permanently store the new settings.
- Click the **Close** button.
- On the Main window, right click on the **Network** item again and select **Read Network Configuration** or click the () icon.

9. The target node should now appear below the **Network** item (see next page):




10. Initial device setup is complete


2.5 ProfiNet Node Device General Configuration

Use this procedure for setting up the ProfiNet node device's general configuration.

1. From the Main window, locate the target Node device from the Device Library list (if the device is not found refer to the “**Importing GSDML file to GX Configurator PN**” procedure above). Click and drag the target device from the Device Library onto the Main window. When released the device will show inside the TCP/IP:... branch and a window will appear for node configuration (see next page):



2. On the Node Window's **General Configuration**, set the Node number (as set by the Initial Device Config procedure above) and name. **Important! Be sure the Name is the same name as set by the Initial Device Config procedure above (letter case CAN be different)** (see next page):



The screenshot shows a software window titled "BNI PNT-508-105-Z015" with a close button in the top right corner. The window has a tabbed interface with the following tabs: "General Configuration", "Module Configuration", "Parameters", "Connection Information", "I/O Data", and "GSDML File". The "General Configuration" tab is currently selected. Inside this tab, there is a section titled "Device Designation" which contains the following fields and controls:


- Name:** A text input field containing the value "IOLINK001".
- Number:** A dropdown menu showing the value "020".
- Link Parameters:** A checkbox that is checked, with the text "Link Parameters" next to it.
- Active Configuration:** A checkbox that is checked, with the text "Active Configuration:" next to it.
- Comment:** A text area containing the text "IO-Link for industrial ethernet; PROFINET IO-Device".

3. Continue to add node devices for each device on the Profinet network.

2.6 ProfiNet Node Device Module Configuration-Port Functions


There are many items that have to be configured and added to the ProfiNet node device to ensure proper process and diagnostic data functionality. This first module configuration procedure will focus on setting up the Parts of the Profinet node device. In most scenarios the hub device ports can be set up for standard I/O or IO-Link communication. The example below will use the Balluff **BNIO05H** node device that can have standard I/O or IO-Link communication on all ports. Other node devices may have more restricted ability for IO-Link configuration. Refer to the node device's user manual for more information.

1. From the Main window, locate the target Node device from the list of node devices listed and double-click it to bring up its configuration page:



2. Click on the **Module Configuration** tab.
3. From the **Configured Modules:** table, double-click on the **Slot 001** folder. Another window will appear to allow port functions to be adjusted (see next page):

Balluff IO-Link Profinet – Setup Guide



The list above shows Port functions for Pin 4 and Pin 2 of standard M12 round micro-connector:



Pin	Function
1	+24 V, 200 mA
2	Input/output
3	GND
4	Input/output
5	FE

Standard I/O

Pin	Function
1	+24 V, 1.6 A
2	Input/output
3	GND
4	IO-Link / input / output
5	n.a.

IO-Link Configuration


For this node device, the IO-Link is enabled on **Pin 4** of each port. Other node devices may handle IO-Link enabling differently. Refer to the node device's user manual for more information.

4. Click on each Port's Pin 4 setting and select **Normally Open** or **Normally Closed Input** or **Output** for standard I/O or **IO-Link**.
 - a. IO-link will not be selectable in GSDML 2.31
 - b. To configure a port as IO-link pull the slot configuration for each slow 2-9(BNI005H) 6-9 as an IO-link configuration
5. Click on each Port's Pin 2 to set standard I/O functionality for Non-IO-Link ports.


2.7 ProfiNet Node Device Module Configuration-IO-Link/Standard I/O Slot Data


After the Profinet Node device's ports and pins have been configured, the IO-Link mapping must be configured for proper IO-Link device functionality. This second module configuration procedure will focus on setting up the "Slots" reserved for IO-Link or Standard I/O. The example below will use the Balluff **BNI005H** node device that can have standard I/O or IO-Link communication on all ports. Other node devices may have more restricted ability for IO-Link configuration. Refer to the node device's user manual for more information.

1. From the Main window, locate the target Node device from the list of node devices listed and double-click it to bring up its configuration page:



2. Click on the **Module Configuration** tab.
3. From the **Configured Modules:** table, click on the **Slot 002 Standard I/O** folder. Slot 002 = Port 0 of the node device, Slot 003 = Port 1, etc. Starting with Slot 002, delete the module types you will be using for


IO-Link by using the () button on the upper right. You should end up with [empty] slots for each port that will be used for IO-Link communication:



- Click on the + next to the **Unknown Category** sub branch in the **Available Modules** branch. From the list of possible IOL mapping, choose the I and/or O bytes that match the target hub device. Each IO-Link hub device may have different mapping. Refer to the user manual for the Process data length. Below is an excerpt from the **BNI003A 16In/16Out IO-Link hub device** (see next page):

Data transmission rate	COM2 (38,4 kBaud)
Frame type	1
Minimal cycle time	3 ms
Process data cycle time	30 ms. at minimal cycle time
Process data length	8 Bytes input, 2 Bytes output

Using the example above, click on the target Slot on the right, then select the appropriate IOL byte

mapping and click the () button to assign it to that slot. See steps below:

Balluff IO-Link Profinet – Setup Guide

The screenshot shows the 'BNI PNT-508-105-Z015' configuration window with the 'General Configuration' tab selected. The window is divided into two main sections: 'Available Modules' on the left and 'Configured Modules' on the right. The 'Available Modules' list includes various IO-Link modules, with 'IOL_I/O_8/_2 byte' highlighted. The 'Configured Modules' table shows the current configuration for slots 000 through 016. Slot 000 is assigned 'BNI PNT-508-105-Z015', slot 001 is assigned 'BNI PNT-508-105-Z015', and slot 002 is assigned 'IOL_I/O_8/_2 byte'. A blue arrow points from the highlighted module in the 'Available Modules' list to the 'Configured Modules' table, indicating the assignment process. Three blue callout boxes provide instructions: Step 1 points to the 'Available Modules' list, Step 2 points to the 'IOL_I/O_8/_2 byte' module, and Step 3 points to the right-pointing arrow button between the two lists.

Step 1: select target IO-Link Slot

Step 2: select the appropriate I/O byte mapping for the target IO-Link device

Step 3: click this button to assign the I/O mapping to the target slot

Slot	Module
000	BNI PNT-508-105-Z015
001	BNI PNT-508-105-Z015
002	IOL_I/O_8/_2 byte
003	[empty]
004	[empty]
005	[empty]
006	Standard I/O
007	Standard I/O
008	Standard I/O
009	Standard I/O
010	[empty]
011	[empty]
012	[empty]
013	[empty]
014	[empty]
015	[empty]
016	[empty]

5. When all IO-Link slots have been assigned click the **OK** button.


Important! When using the Balluff BIS013W RFID node device, ALL four slots for RFID antennae MUST be configured regardless of actual hardware!

Important! It is recommended to set IO-link ports to 16 IN/16 Out to allow maximum flexibility in configuration.

2.8 ProfiNet Node Device Module Configuration-Node Diagnostics Slot Data

After the Profinet Node device's IO-Link hubs have been configured, the Profinet node device's diagnostic data must be mapped to enable this functionality. This third module configuration procedure will focus on setting up the "Slots" reserved for Short Circuit, Module Error, IOL Diagnostics Enabled/Disabled, etc. The example below will use the Balluff **BNIO05H** node device that can have standard I/O or IO-Link communication on all ports. Other node devices may have more restricted ability for IO-Link configuration. Refer to the node device's user manual for more information.

1. From the Main window, locate the target Node device from the list of node devices listed and double-click it to bring up its configuration page:



2. Click on the **Module Configuration** tab.
3. From the **Configured Modules:** table, click on the **Slot 0010 [empty]** folder.
4. Using the steps show in the previous procedure, "**ProfiNet Node Device Module Configuration-IO-Link/Standard I/O Slot Data**", add ALL of the modules shown below. The order of the slot insertion does NOT need to be identical as long as they are on the list of Configured Modules:


Balluff IO-Link Profinet – Setup Guide


Slot	Module
010	IO-Link communication state
011	Station diagnostic
012	Periphery error
013	Sensor supply short circuit
014	Display Leds
015	Actuator shutdown pin 4
016	Actuator shutdown pin 2
017	Actuator warning pin 4
018	Actuator warning pin 2
019	Output pin 4
020	Output pin 2
021	IO-Link diagnosis enable / disable
022	[empty]
023	[empty]
024	[empty]
025	[empty]

5. When all IO-Link slots have been assigned click the **OK** button.


2.9 Profinet and Main PLC Settings-CPU Project Association and Update Parameters


Before downloading a Profinet configuration project, the PLC project for the main CPU must be assigned in the CPU Configuration of the PN Configurator software. When mapping is added, edited, or deleted, PN configurator needs to update the PLC project's PLC parameters to reflect the new device mapping. Once this is complete, the Parameters can be updated online to the Main CPU and PN Controller and the offline PLC project. This second PLC Settings procedure will show how to set up plc project association and perform an **Update Parameters** operation.



1. From the Main **Menu** window, select **File>PLC Settings** or click the () button.
2. On the PLC Settings window, click on the **Configure...** button:




3. On the **CPU Info** list, click on the blank space next to **PLC Project**:




4. Use the () button to select your target project.
5. Once selected, click **OK** to store the new setting.
6. From the **PLC Settings** window, click the **Update Parameters...** button.
7. Be sure both Main and PN controller checkboxes are checked and click OK.
8. Click **Yes**. If parameters successfully update in both CPUs and the PLC the project, you should get three message boxes:



Balluff IO-Link Profinet – Setup Guide





9. Click **OK** three times to clear all message boxes.
10. Click **OK** on the **PLC Settings** to close the window.
11. Click the Save icon () to permanently save new settings.

2.10 Saving and Downloading Configuration to PN Controller

After all the preceding steps have been complete:

- New Configurator created
- GSDML files imported
- Main CPU and PN Controller configured
- Node and Hub devices mapped
- Parameters in Main CPU and PN Controller update


Then, the final configuration can be saved and downloaded to the PN controller. Only after these steps are completed with the PN controller reflect the new configuration:

1. From the Main **Menu** window, select **File>Save** or click the () button.
NOTE: IF there are any parameters that need to be update to the Main CPU and the PN Controller, the PLC Settings will appear. Perform the “Update Parameters” procedure explained above to complete the file save.
2. After parameters are updated and file is saved, select **File>Download Configuration** or click the () icon.
3. When the Output Message View on the bottom of the main window says **“The configuration is successfully downloaded.”**
4. Reset your Main CPU processor for changes to take effect.

2.11 Referencing I/O/Diagnostic Data Mapping

When a Profinet network configuration is completed, the actual device mapping for each slot of each node and hub can be referenced within the GX Configurator PN software.

Most times, the GXWorks 2 PLC template project will automatically handle all node and hub data for diagnostic and parameter display/manipulation but there may be a need to reference this material for added features.

1. From the Main **Menu** window, select **File>PLC Settings** or click the () button.
2. On the PLC Settings window, click on the **I/O Documentation...** button.
3. Click **OK** if any warnings appear (usually it's just to truncate the name of a slot element).
4. The resulting report will load on your default web browser on your PC.
5. The report is broken up into 2 major areas:
 - a. A master slot table of all slave nodes on the Profinet network with hyperlink shortcuts to more details
 - b. Details tables for each slot configured for each slave node on the Profinet network.

See next page for Header data on this report:

Balluff IO-Link Profinet – Setup Guide

Example with two Profinet node devices (No 20 and 21)

Project: DEMO

Slave No.	Name	Model	Modules		
			Slot	Model	Global Var. In / Global Var. Out
20	bnipnt508105z015	BNI PNT-508-105-Z015	0	BNI PNT-508-105-Z015	- / -
			1	BNI PNT-508-105-Z015	- / -
			2	IO_L_I/O_8/_2 byte	SLV020SLOT002DataStructIn / SLV020SLOT002DataStructOut
			6	Standard I/O	- / -
			7	Standard I/O	- / -
			8	Standard I/O	- / -
			9	Standard I/O	- / -
			10	IO-Link communication state	SLV020SLOT010DataStructIn / -
			11	IO-Link diagnosis enable / disable	- / SLV020SLOT011DataStructOut
			12	Station diagnostic	SLV020SLOT012DataStructIn / -
			13	Periphery error	SLV020SLOT013DataStructIn / -
			14	Sensor supply short circuit	SLV020SLOT014DataStructIn / -
			15	Actuator shutdown pin 4	SLV020SLOT015DataStructIn / -
			16	Actuator shutdown pin 2	SLV020SLOT016DataStructIn / -
			17	Actuator warning pin 4	SLV020SLOT017DataStructIn / -
			18	Actuator warning pin 2	SLV020SLOT018DataStructIn / -
			19	Display Leds	- / SLV020SLOT019DataStructOut
40	bnipnt508105	BNI PNT-508-105-Z015	0	BNI PNT-508-105-Z015	- / -
			1	BNI PNT-508-105-Z015	- / -
			2	IO_L_I_4 byte	SLV040SLOT002DataStructIn / -
			3	Standard I/O	- / -
			4	Standard I/O	- / -
			5	Standard I/O	- / -
			6	Standard I/O	- / -
			7	Standard I/O	- / -
			8	Standard I/O	- / -
			9	Standard I/O	- / -
			10	IO-Link communication state	SLV040SLOT010DataStructIn / -
			11	IO-Link diagnosis enable / disable	- / SLV040SLOT011DataStructOut
			12	Station diagnostic	SLV040SLOT012DataStructIn / -
			13	Periphery error	SLV040SLOT013DataStructIn / -
			14	Sensor supply short circuit	SLV040SLOT014DataStructIn / -
			15	Actuator shutdown pin 4	SLV040SLOT015DataStructIn / -
			16	Actuator shutdown pin 2	SLV040SLOT016DataStructIn / -
			17	Actuator warning pin 4	SLV040SLOT017DataStructIn / -
			18	Actuator warning pin 2	SLV040SLOT018DataStructIn / -
			19	Display Leds	- / SLV040SLOT019DataStructOut

See next page for Details:

Basic node device info as configured in the General

Slot Data with clickable hyperlinks as configured in the

bnipnt508105z015.Module Slot 2 : SLV020SLOT002DataStructIn

Element Identifier	Element Type	Class	Buffer MIT-Address
SLOT002_INPUT_2_BYTES	ARRAY [0..63] OF BOOL	Input	W1415.0

bnipnt508105z015.Module Slot 2 : SLV020SLOT002DataStructOut

Element Identifier	Element Type	Class	Buffer MIT-Address
SLOT002_OUTPUT_2_BYTES	ARRAY [0..15] OF BOOL	Output	W1201.0

bnipnt508105z015.Module Slot 10 : SLV020SLOT010DataStructIn

Element Identifier	Element Type	Class	Buffer MIT-Address
SLOT010_KOMMUNIKATIONSSTATUS	ARRAY [0..7] OF BOOL	Input	W1419.0
SLOT010_BIT_KOMMUNIKATIONSSTATUS	ARRAY [0..7] OF BOOL	Input	W1419.0

bnipnt508105z015.Module Slot 11 : SLV020SLOT011DataStructOut

Element Identifier	Element Type	Class	Buffer MIT-Address
SLOT011_DIAGOSIS_ENABLE_DISABLE	ARRAY [0..7] OF BOOL	Output	W1202.0
SLOT011_BIT_DIAGOSIS_ENABLE_DISA	ARRAY [0..7] OF BOOL	Output	W1202.0

bnipnt508105z015.Module Slot 12 : SLV020SLOT012DataStructIn

Element Identifier	Element Type	Class	Buffer MIT-Address
SLOT012_STATION_DIAGNOSTIC	ARRAY [0..7] OF BOOL	Input	W141A.0
SLOT012_BIT_STATION_DIAGNOSTIC	ARRAY [0..7] OF BOOL	Input	W141A.0

bnipnt508105z015.Module Slot 13 : SLV020SLOT013DataStructIn

Element Identifier	Element Type	Class	Buffer MIT-Address
SLOT013_PERIPHERY_ERROR	ARRAY [0..7] OF BOOL	Input	W141B.0
SLOT013_BIT_PERIPHERY_ERROR	ARRAY [0..7] OF BOOL	Input	W141B.0

bnipnt508105z015.Module Slot 14 : SLV020SLOT014DataStructIn

Element Identifier	Element Type	Class	Buffer MIT-Address
SLOT014_SENSOR_SUPPLY_SHORT_CIRC	ARRAY [0..7] OF BOOL	Input	W141C.0
SLOT014_BIT_SENSOR_SUPPLY_SHORT	ARRAY [0..7] OF BOOL	Input	W141C.0

Slot Data for the first IO-Link device for node device 20. Actual breakdown of I/O signals and diagnostic indicators can be referenced in that device's User Guide

Slot Data for the node device's diagnostic data

See next page for more information:

Balluff IO-Link Profinet – Setup Guide

Slave No.	Name	Model	Modules		
			Slot	Model	Global Var. In / Global Var. Out
			0	BNI PNT-508-105-Z015	- / -
			1	BNI PNT-508-105-Z015	- / -
			2	IOL_I/O__8/_2 byte	SLV020SLOT002DataStructIn / SLV020SLOT002DataStructOut
			6	Standard I/O	- / -

Clicking on one of these hyperlinks will navigate to the appropriate details section of the report

bnipnt508105z015.Module Slot 2 : SLV020SLOT002DataStructIn

Element Identifier	Element Type	Class	Buffer MIT-Address
SLOT002_INPUT_2_BYTES	ARRAY [0..63] OF BOOL	Input	W1415.0

bnipnt508105z015.Module Slot 2 : SLV020SLOT002DataStructOut

Element Identifier	Element Type	Class	Buffer MIT-Address
SLOT002_OUTPUT_2_BYTES	ARRAY [0..15] OF BOOL	Output	W1201.0

Number of bits used in this slot data.
Since this is an 8-byte slot, 64 bits are

Starting device address as this slot
data as configured in the PLC

3 GX WORKS 2 PLC SETUP

From the template project, much of the Profinet and IO-Link Diagnostics functionality is configured to allow for dynamic changes to the setup. However, some verification and changes are required for proper Profinet operation on a target system.

The template project is designed for a Q06UDV processor, with a MultiCPU rack, with a PN controller in the CPU slot next to the Q06UDV CPU.

In subsequent sections we will cover:

1. PLC Parameters and required programming
2. IO-Link device configuration function blocks
3. IO-Link Master Configuration
4. IO-Link Diagnostics required programming
5. IO-Link Device Process Data function blocks
6. RFID required programming

3.1 PLC Parameters and required Programming


Whether starting with the template project or importing or copy/pasting elements into an existing project, there are common PLC parameters required for correct operation.

PLC file registers are used in our example template, the maximum non-extended size of a Q06UDV, 384 K points is defined.

This project uses retentive registers for storing data through a power cycle.

IO-link Data (IOLDB) needs to be stored in retentive word memory consisting of 9340 words. The template project stores this data within ZR300000-ZR309339.

This can be configured from the Global Label settings of the PN_IOLDiag library



Profinet Diagnostics needs to store the deactivated nodes(128 bits) in retentive bit memory. The template project uses B8200-B82FF and W8200-82FF to store all Profinet Diagnostic Data

Balluff IO-Link Profinet – Setup Guide

Parameter Setting

PLC Name | PLC System | PLC File | PLC RAS | Boot File | Program | SFC | **Device** | I/O Assignment | Multiple CPU Setting | Built-in Ethernet Port Setting

	Sym.	Dig.	Device Points	Latch (1) Start	Latch (1) End	Latch (2) Start	Latch (2) End	Local Device Start	Local Device End
Input Relay	X	16	8K						
Output Relay	Y	16	8K						
Internal Relay	M	10	60K						
Latch Relay	L	10	32K			0	32767		
Link Relay	B	16	60K			4000	FFFF		
Annunciator	F	10	2K						
Link Special	SB	16	2K						
Edge Relay	V	10	2K						
Step Relay	S	10	8K						
Timer	T	10	2K						
Retentive Timer	ST	10	128						
Counter	C	10	1K						
Data Register	D	10	12K						
Link Register	W	16	0K						
Link Special	SW	16	2K						
Index	Z	10	20						

Device Total: 28.9 K Words
Word Device: 17.2 K Words
Bit Device: 172.3 K Bits

The total number of device points is up to 40K words.
Latch(1) : Able to clear the value by using latch clear.
Latch(2) : Unable to clear the value by using latch clear. Clearing will be executed by program.
Scan time is extended by the latch range setting (including L).
If the latch is necessary, please set the required minimum latch range.
When using the local devices, please do the file setting at PLC file setting parameter.

File Register Extended Setting

Capacity: 384 K Points

	Sym.	Dig.	Device Points	Latch (1) Start	Latch (1) End	Latch (2) Start	Latch (2) End	Device No. Start	Device No. End
File Register	ZR(R)	10	324K			260000	331775	ZR0	ZR331775
Extended Data	D	10	0K						
Extended Link	W	16	60K	4000	FFFF			W0	WEFFF

Following setting are available when select "Use the following file" in file register setting of PLC file setting.
- Change of latch(2) of file register.
- Assignment to expanded data register/expanded link register of a part of file register area.


Indexing Setting for Device
32Bit Indexing
☐ Use Z Z After (0 -- 18)
☒ Use ZZ

Latch Interval Setting
☐ Time Setting When time setting is selected, latch by END processing after the specified time has passed.
☒ Per Scan

Print Window... | Print Window Preview | Acknowledge XY Assignment | Default | Check | End | Cancel

Proper operation of IO-Link diagnostics requires the use and operation of the MELPT_APP_ProfinetDiag function block. The template version uses version 3.03.

3.1.1 Configuration of MELPT_APP_ProfinetDiag



Purpose: Turns on the cyclic communication functionality of the PN controller. Determines Fieldbus Status for individual nodes, allows the ability to reserve/activate a node. Retrieves channel diagnostics. Provides alarm summary bits

User Configuration: Profinet controller location, attaching alarm outputs to HMI alarm memory.

This function block is used to monitor overall node health for the fieldbus and provide detailed diagnostics for the selected fieldbus node.

For this function block to operate properly the User library installed by GX Configurator –PN: PROFINET_IO_ME1PN1FW_Q, must be installed and updated with the correct PLC registers. The installation of Profinet_IO_ME1PN1FW_Q is achieved through configuration of the PN controller from GX Configurator_PN. To install this library please refer to section 2.9 of this document.

During the write process to the PLC, GX Configurator –PN will install the user library and update the labels with the devices listed in PLC Settings of GX Configurator_PN.

Additionally the user library PN_accessory_v120 needs to be installed, this library contains the acyclic read and write function needed to retrieve channel diagnostics.

Note: If a diagnostic is occurring when the io-link diagnostic is disabled. An electrical change has to occur once it is enabled for the diagnostic to be reported to the fieldbus diagnostic programming.

Balluff IO-Link Profinet – Setup Guide

FB Name

MELPT_APP_ProfinetDiag

Item	Description
Function overview	This function block monitors Profinet node health, starts the fieldbus, and allows a method to reserve/activate nodes
Symbol	<div style="display: flex; justify-content: space-between;"> <div style="width: 30%;"> <p>Input Pins</p> <p>Profinet Module Inputs</p> <p>Profinet Node Health</p> <p>SD397/SD398</p> <p>Profinet Module Error Code</p> <p>Start Command Pulse</p> <p>Mute Time</p> <p>ScreenActive.ProfinetDiag</p> <p>FieldbusDiag.Activate Button</p> <p>Reset Status HMI PB</p> </div> <div style="width: 40%; text-align: center;"> <p>MELPT_APP_ProfinetDiag</p> </div> <div style="width: 30%;"> <p>Output Pins</p> <p>Profinet Module Outputs</p> <p>Host OK</p> <p>Slave Warning Message</p> <p>Slave Error Message</p> <p>Master Module Error</p> <p>Latched Deactivated nodes</p> <p>Selected Node is Deactivated</p> <p>Array of Node Status</p> <p>Selected Error Code</p> <p>Selected Status</p> <p>Module Error Code</p> <p>First Node Number</p> <p>Last Node Number</p> <p>Cursor Control</p> <p>Cursor Control</p> <p>Selected Node Manufacturer ID</p> <p>Selected Node Slot Number</p> <p>Selected Node Slot Status</p> <p>Selected Node Slot Ident</p> <p>Selected Node SubSlot Number</p> <p>Selected Node Subslot Status</p> <p>Selected Node SubSlot Ident</p> <p>Channel Status</p> <p>Channel Number</p> <p>Channel Type</p> <p>Channel Data Format</p> <p>Channel Error</p> <p>Extended Channel Error</p> <p>Device Name</p> <p>Mac Address</p> <p>IP address of device</p> <p>Gateway Address</p> <p>Subnet Mask</p> <p>Order Number of Device</p> <p>update Bit</p> <p>HMI Selected Node</p> </div> </div>

Balluff IO-Link Profinet – Setup Guide

Item	Description		
Applicable Hardware			
	Series	Model	Serial Restriction
	MELSEC-Q series	Universal Model PLC	None
	MELSEC-Q series C CPU	ME1PN1FW-Q	None
	GOT 1000 series	GT16(800*600) or Higher	None
Applicable Software			
	Series	Version	
	GX Works 2	1.540	
	GT Designer 3	1.136	
	Configurator-PN	1.03	
Programming language	Structured Ladder/FBD		
Number of Ladder Steps	QnU: 1048 steps *The number of steps of the FB program depends on the CPU Model that is used and input and output definition		
Device Memory Used	1852 bits 1426 words 2 timer		
Compiling method	Macro type;		
Execution type	Real-time Execution		

Balluff IO-Link Profinet – Setup Guide

Item	Description
Dependencies	<p>This FB requires the following SDT from the Profinet Module library:</p> <p>tPN_MGMT_INPUTS,</p> <p>tPN_MGMT_OUTPUTS</p> <p>and the following FB from the PN_accessory library</p> <p>PN_Read_Rec</p> <p>PN_AcyclicBufferCheck</p>
Function description	This function block enabled the ProfiNet fieldbus, monitors node health, sets alarms for node issues, and interrogates an individual node for channel diagnostics
Restrictions and precautions	This function block uses Z16
Timing chart	<p>The timing chart illustrates the sequence of signals for the function block. The signals shown are:</p> <ul style="list-style-type: none"> i_bPN_StartCMD: A pulse signal that starts at the beginning of the sequence. o_stPN_MGMTOutputs.IOC_Start_Stop: A pulse signal that occurs after i_bPN_StartCMD. i_stPN_MGMTInputs.IOC_STS_STARTED: A signal that becomes active (high) after o_stPN_MGMTOutputs.IOC_Start_Stop. o_bLinkOK: A signal that becomes active (high) after i_stPN_MGMTInputs.IOC_STS_STARTED. i_tStartupMuteTime: A time period indicated by a vertical dashed line, starting from the beginning of the sequence.

FB Error Code

Error Code	Description
0	No Error
H100 (256)	Not a Profinet Module check i_uCPUStatusWord
H101 (257)	Module Error Code Present

Balluff IO-Link Profinet – Setup Guide

Error Code	Description
H102 (258)	Configuration Error Detected

Labels

Input labels

User Input	Symbol Name	Var_Input name	Data Type	Setting range	Description
	Profinet Module Inputs	i_stPN_MGMTInputs	tPN_MGMT_INPUTS		Profinet Controller Management Input SDT
	Profinet Node Health	i_uPN_AdvStatus	Word[Unsigned](0..63)		Advanced Status of 128 nodes
X	SD397/SD398	i_uCPUStatusWord	Word[Unsigned]	SD397 or SD398	Data for MultiCPU Enter SD397 if CPU2 SD398 if CPU3
	Profinet Module Error Code	i_uAdvancedDiagErrorCode	Word[Unsigned]		Error Code from C-CPU
	Start Command Pulse	i_bPN_StartCmd	Bit		User Defined Start Profinet
X	Mute Time	i_tStartupMuteTime	Time	T#1ms – t#32s	Timer for not recovering status of slaves
	ScreenActive.ProfinetDiag	i_bDiagScreenActive	Bit		When Fieldbus Diagnostic Screen is Active
	FieldbusDiag.Activate Button	i_bActivate_PB	Bit		Activate Node

Balluff IO-Link Profinet – Setup Guide

User Input	Symbol Name	Var_Input name	Data Type	Setting range	Description
	Reset Status HMI PB	i_bResetStatusofSelectedNode	Bit		Reset Status

Input/Output labels

User Input	Name	Var_In_Out name	Data Type	Setting range	Description
	update Bit	io_bUpdateScreen	Bit		Refresh Diag Screen
	HMI Selected Node	io_wHMISelectedNode	Word[Signed]		HMI numeric Input of FDL address

Output labels

Name	Var_Output name	Data Type	Description
FB Execute normal	o_bOK	Bit	When TRUE, indicates processing has completed normally
FB Execute abnormally	o_bERR	Bit	When TRUE, indicates an Error has occurred
FB Error Code	o_uErrID	Word[Unsigned]	FB Error Code Output
Profinet Module Outputs	o_stPN_MGMT Outputs	tPN_MGMT_OUTP UTS	outputs to ProfiNet control
Host OK	o_bLinkOK	Bit	Status of Data Link
Slave Warning Message	o_bSlaveWarning	Bit	A slave currently has diagnostic message
Slave Error Message	o_bSlaveError	Bit	A slave currently is disconnected

Balluff IO-Link Profinet – Setup Guide

Name	Var_Output name	Data Type	Description
Master Module Error	o_bMasterError	Bit	A slave currently is disconnected
Latched Deactivated nodes	o_bDeactivated Nodes	Bit(0..127)	Temporary Reserved Nodes
Selected Node is Deactivated	o_bDeactivated NodeIndicator	Bit	HMI Indicator the selected Node is Deactivated
Array of Node Status	o_unNodeStatus	Word[Unsigned](0..127)	Node Status Array
Selected Error Code	o_uSelectedErrorCode	Word[Unsigned]	Node Status Array
Selected Statis	o_uSelectedStatus	Word[Unsigned]	Selected node Status
Module Error Code	o_uModuleErrorCode	Word[Unsigned]	Profibus HMI Module Fault Code
First Node Number	o_wFirstNodeNumber	Word[Signed]	First Node Number
Last Node Number	o_wLastNodeNumber	Word[Signed]	Last Node Number on Machine
Cursor Control	o_bOnFirstNode	Bit	HMI Indicator for Node Selection Control
Cursor Control	o_bOnLastNode	Bit	HMI Indicator for Node Selection Control
Selected Node Manufacturer ID	o_uManufacturerID	Word[Unsigned]	Manufacturer ID from I&M0
Selected Node Slot Number	o_uSlot	Word[Unsigned]	Slot Number of

Balluff IO-Link Profinet – Setup Guide

Name	Var_Output name	Data Type	Description
Selected Node Slot Status	o_uSlotStatus	Word[Unsigned]	Slot Status
Selected Node Slot Ident	o_dSlotIdent	Double Word[Unsigned]	Slot Ident Number
Selected Node SubSlot Number	o_uSubSlot	Word[Unsigned]	Subslot Number
Selected Node Subslot Status	o_uSubSlotStatus	Word[Unsigned]	Subslot Status
Selected Node SubSlot Ident	o_dSubSlotIdent	Double Word[Unsigned]	SubSlot Ident
Channel Status	o_uChannelStatus	Word[Unsigned]	Channel Status
Channel Number	o_uChannelNumber	Word[Unsigned]	Channel Number
Channel Type	o_uChannelType	Word[Unsigned]	Channel Type
Channel Data Format	o_uChannelDataFormat	Word[Unsigned]	ChannelDataFormat
Channel Error	o_uChannelError	Word[Unsigned]	Channel Error Code
Extended Channel Error	o_uExtendedChannelError	Word[Unsigned]	Extended Channel Error Code
Device Name	o_uChasisData	Word[Unsigned](0..15)	Chassis data

Balluff IO-Link Profinet – Setup Guide

Name	Var_Output name	Data Type	Description
Mac Address	o_uMacAddress	Word[Unsigned](0..2)	MAC Address
IP address of device	o_uIPAddress	Word[Unsigned](0..1)	IP Address
Gateway Address	o_uGatewayAddress	Word[Unsigned](0..1)	Gateway Address
Subnet Mask	o_uSubnetMask	Word[Unsigned](0..1)	Subnet Mask
Order Number of Device	o_uOrderNumber	Word[Unsigned](0..9)	Order Number

FB Version Upgrade History

Version	Description
2.10	This function block was introduced
3.00	Modified Format to display channel diagnostics
3.01	Recode reduces memory usage
3.03	MC/MCR, recode for memory reduction, correct status issue.

SDT Usage

tPN_MGMT_Outputs

Global Label: vPN_MGMT_Outputs		
Member	Type	Usage

Balluff IO-Link Profinet – Setup Guide

Global Label: vPN_MGMT_Outputs		
Member	Type	Usage
.IOC_Start_Stop	Bit	Starts Profinet Communication, Set by this FB
ACYC_HSK_Y_Req1.Execute	Bit	Monitor to see if acyclic buffer in use
ACYC_HSK_Y_Req2.Execute	Bit	Monitor to see if acyclic buffer in use
.IOD_MGT_Mode	Bit(0..127)	Used to deactivate nodes
.IOD_CMD_HSK_Y	Bit(0..127)	Used to deactivate nodes
IOD_START_STOP_DEV	Bit(0..127)	
IOD_MGT_ALARM	Bit(0..127)	
IOD_CONSIST	Bit(0..127)	
IOD_INPUT_HSK_Y	Bit(0..127)	
IOD_OUTPUT_HSK_Y	Bit(0..127)	

tPN_MGMT_INPUTS

Global Label: vPN_MGMT_Inputs		
Member	Type	Usage
IOC_STS_CONFIG_OK	Bit	Needed to turn on ProfiNet
IOC_STS_CONFIG_DOWNLOADING	Bit	
IOC_STS_KEYFILE_ERROR	Bit	
IOC_STS_STARTED	Bit	Handshake from module that it started
IOC_STS_ERROR_DIAG_SET	Bit	

Balluff IO-Link Profinet – Setup Guide

Global Label: vPN_MGMT_Inputs		
Member	Type	Usage
IOC_STS_PLC_WD_ERR	Bit	
IOD_CMD_HSK_X	Bit(0..127)	
IOD_INPUT_HSK_X	Bit(0..127)	
IOD_OUTPUT_HSK_X	Bit(0..127)	
ACYC_HSK_X_RES1_COMPLETE D	Bit	Monitor to see if acyclic buffer in use
ACYC_HSK_X_RES2_COMPLETE D	Bit	Monitor to see if acyclic buffer in use
ACYC_HSK_X_RES1_ACCEPTED	Bit	Monitor to see if acyclic buffer in use
ACYC_HSK_X_RES2_ACCEPTED	Bit	Monitor to see if acyclic buffer in use
IOD_ALARM_IND	Bit(0..127)	
IOD_CONN_STS	Bit(0..127)	Used to determine status
IOD_ERR_STS	Bit(0..127)	Used to determine status

MELPT_APP_FieldbusDiag

System Label: ProfinetDiag		
Member	Type	Usage
HostOK	Bit	Profinet Card Running, set by this FB
Update	Bit	Set by HMI, requires refresh of detailed diagnostic data
ActivateDeactivate_PB	Bit	HMI PB to change activated status
ActiveNode_Ind	Bit	HMI Indicator of activation status

Balluff IO-Link Profinet – Setup Guide

System Label: ProfinetDiag		
Member	Type	Usage
ResetStatus	Bit	Reset Status PB From HMI. Seta Status to zero
OnFirstNode	Bit	Set by Function block to limit HMI PB from decrementing too low
OnLastNode	Bit	Set by Function block to limit HMI PB from incrementing too high
WriteCheck	Bit(0..7)	
DeactivatedNodes	Bit(0..127)	Stored Values of Deactivated nodes
IMSupported	Bit(0..15)	
LocalNetworkNumber	Word[Unsigned]	
LocalStationNumber	Word[Unsigned]	
FieldbusModuleCommentNumber	Word[Unsigned]	
FieldbusModuleFault	Word[Unsigned]	Profinet Module Error
FirstConfiguredNode	Word[Signed]	Node Number of first configured node
LastConfiguredNode	Word[Signed]	Node Number of Last configured node
SelectedNode	Word[Signed]	HMI Selected node, this is FB limited by First and Last Configured Node
SelectedStatus	Word[Unsigned]	Status of Selected Node
SelectedDeviceDiagnostic	Word[Unsigned]	
ManufacturerID	Word[Unsigned]	Retrieved during acyclic requests manufacturer code
DeviceID	Word[Unsigned]	

Balluff IO-Link Profinet – Setup Guide

System Label: ProfinetDiag		
Member	Type	Usage
ChannelStatus	Word[Unsigned]	Retrieved during acyclic requests channel diagnostics
ChannelNumber	Word[Unsigned]	Retrieved during acyclic requests channel number under error
ChannelType	Word[Unsigned]	Retrieved during acyclic requests channel diagnostics channel type
ChannelDataFormat	Word[Unsigned]	Retrieved during acyclic requests channel diagnostics data format
ChannelError	Word[Unsigned]	Retrieved during acyclic requests channel error
ExtendedChannelError	Word[Unsigned]	Retrieved during acyclic requests channel extended channel error
Slot	Word[Unsigned]	Retrieved during acyclic requests channel diagnostics
SlotStatus	Word[Unsigned]	Retrieved during acyclic requests channel diagnostics
SubSlot	Word[Unsigned]	Retrieved during acyclic requests channel diagnostics
SubSlotStatus	Word[Unsigned]	Retrieved during acyclic requests channel diagnostics
SlotIDent	Double Word[Unsigned]	Retrieved during acyclic requests channel diagnostics
SubSlotIDent	Double Word[Unsigned]	Retrieved during acyclic requests channel diagnostics
ChasisData	Word[Unsigned](0..15)	Retrieved during acyclic requests includes device name
MacAddress	Word[Unsigned](0..255)	Retrieved during acyclic requests

Balluff IO-Link Profinet – Setup Guide

System Label: ProfinetDiag		
Member	Type	Usage
IPAddress	Word[Unsigned](0..1)	Retrieved during acyclic requests
SubnetMask	Word[Unsigned](0..1)	Retrieved during acyclic requests
GatewayAddress	Word[Unsigned](0..1)	Retrieved during acyclic requests
OrderNumber	Word[Unsigned](0..9)	Retrieved during acyclic requests
PlantID	Word[Unsigned](0..15)	
LocationName	Word[Unsigned](0..10)	
InstallationDate	Word[Unsigned](0..7)	
Description	Word[Unsigned](0..23)	
LinkTime	Word[Unsigned](0..2)	
NodeStatus	Word[Unsigned](0..127)	Status of all nodes determined by the FB

3.1.2 Necessary System Labels

The HMI project is common between Profinet and Profibus implementations of this project

ProfinetDiag(for Profinet diagnostics display)

ProfibusDiag(for Profibus diagnostics display)

GOTRFID (for manual RFID interface)

IOLinkDiag (For IO-link diagnostics features)

1 instance of IOlinkPressureSwitch for each pressure switch graphic needed.

A PLC device register is assigned to each system label, this prevents synching issues with the PLC project when additional programming and labels are added to the project.

3.2 IO-Link device configuration function blocks

Purpose: Provide System information and default parameter values to the PLC so device specific information can be displayed properly, and the device can be parameterized.

User Configuration: The function block must be in the initial or active scan, EN must be TRUE, Device Number must be unique and between 1-10, Diagnostic Graphic Number must be between 1 and 32767. A unique device description should be provided.

The Balluff IOL_CFG library contains multiple function blocks containing device information needed for proper program execution. There are function blocks for IOL-link devices for the following families.

Analog

IO Hubs

Positioning

Pressure


RFID FB

SmartLights

Valve Interface

Up to 10 devices total can be selected and placed into the initial scan of the PLC. These function blocks only have to be executed once the data contained within the function block is transferred to the data structure array IOLCFG

Configuration function block setup



3.2.1 FB Inputs

The EN pin must be set to true for the information to be available, set to false if the configuration is not desired.

DiagGraphicNumber

The HMI window number for this device, this is a value between 1 and 32767 corresponding to the diagnostic window displayed on the HMI for the specific device.

DeviceNumber

A value 1-10 that corresponds to the array element within IOLDeviceCFG, where this data will be stored. This number needs to be unique between all the configuration function blocks.

DefaultUnitType

This element only exists for Pressure Switches

Enter one of the following values:

0=bar

1=mbar

2=PSI

3=MPa

Default SP1 & Default SP2

The default set points when first configuring the device, this value is a raw device value

Device Description

This is the text that will be displayed on the HMI Maintenance Screen. There is a 24 character maximum.

3.2.2 FB Outputs

When the device number is outside the range of 1-10 FB_ERR is true

The ERRID will be 256(H100)

When the graphic number is outside the allowable range of 1 to 32767. FB_ERR is True.

The ERRID will be 257(H101)

For Pressure Switches an additional FB_ERR can occur when the value of DefaultUnitType is less than zero, or greater than three.

The ERRID will be 258(H102)

When ERRID is non-zero FB_ERR is TRUE.

When ERRID is zero FB_OK is TRUE.


The output of all CFG function blocks is IOLDeviceCFG which is array of CFG structures. Each individual block stores data in 1 element of this structure array.

3.3 IO-Link Master Configuration

Three function blocks exist within the Balluff IOL_CFG library, an instance for each IO-link master on your PLC needs to be added to the scan, the maximum number of IO-Link Masters is twenty.

The three function blocks included are:

- Balluff_PN_BIS013W
 - Balluff_PN_BNI004U
 - Balluff_PN_BNI005H
- **Purpose:** this function block determines how a master is configured, retrieves and organizes diagnostic data for the master also retrieves process data for any IO-link devices and stores appropriately.
 - **User Configuration:** The user must properly populate the following pins:
 - PNCPUNumber
 - NodeNumber
 - DiagnosticGraphic Number
 - Maintenance Graphic Number
 - IOLDB element number
 - Diagnostics Enabled auto-refresh address



3.3.1 FB Inputs

PNCPUNumber

- 1: When the PN Controller is next to the PLC CPU
- 2: When the PN controller is one slot away from the PLC CPU

NodeNumber

This is a value between 0 and 127 and corresponds to the value set to the specific node in GX configurator PN

StatusArray

This is the node status word array that is output from MELPT_APP_ProfinetDiag

DiagnosticGraphicNumber

This is the HMI Window Number that displays the master diagnostics

Maintenance Graphic Number

This is the HMI window Number that displays the maintenance data

3.3.2 FB Outputs

Configured

This value is True after the slot configuration of the node is retrieved

IOLDB

Attach the IOLDB element where you want to store the settings for this master. The element number must be unique and a value between 1 and 20.


DiagnosticsEnabled

This is the output from IOLDB to the IO-link Master. This signal can be used to mask channel diagnostics on the fieldbus related to IO-link.

Note: If a diagnostic is occurring when the io-link diagnostic is disabled. An electrical change has to occur once it is enabled for the diagnostic to be reported to the fieldbus diagnostic programming.

The Auto refresh address of the fieldbus must be attached to this pin. The auto refresh register can be obtained by following the instructions in 2.11

3.3.3 Program Flow



3.4 IO-Link Diagnostics required programming

Two function blocks are required to provide the functionality of this project that are not Device related.

3.4.1 IOLDiag_PN_module_Lookup

Purpose: Interrogates all elements of IOLDB, determines when a new IO-link connection is made, sends the stored parameters to the IO-Link Device.

User Configuration: Make sure the FB is scanned and required libraries are installed.

This function block is in charge of acyclic communication with an IO-Link device, and the writing of parameters to the device.


This function block will check the comm state for every IO-Link port. If communication has not been established the Manufacturer and Device ID are retrieved and compared to the available configurations if a match is made, then the configuration is checked for the same type. If a second match is made, parameters are written to the device if the configuration has them.

This function block requires the libraries:

PN_accessory_v120

And

Profinet_IO_ME1PN1FW_Q.



3.4.1.1 Inputs

Set the EN pin to TRUE

The configuration data IOLDeviceCFG is connected to i_stCFG, this structure was populated in section 3.2 by the initial scan sequence

3.4.1.2 Outputs


HMI Diag

The HMI System variables are retrieved and compared to the Label IOLinkDiag needs to be connected to the output HMI Diag

IOLDB

The Global Label IOLDB is attached to the output IOLDB


3.4.1.3 IOLDiag_PN_Module_Lookup FlowChart



3.4.2 IOLDiag_HMI

Purpose: This function block takes all the stored data from the master function blocks, determines error status and presents selected information to the HMI. In addition it accepts input from the HMI to modify the data structures.

User Configuration: Attach Flag Output Pins to the Alarming System of the HMI



3.4.2.1 FB Inputs

Set the EN pin to TRUE

CFG

The configuration data **IOLDeviceCFG** is connected to **i_stCFG**, this structure was populated in section 3.2 by the initial scan sequence

FieldbusNodeStatus

This is the node status word array that is output from **MELPT_APP_ProfinetDiag**

3.4.2.2 FB Outputs

HMIData

The data formatted to and from the HMI. **IOLinkData**.

IOLDB

The Global Label **IOLDB** is attached to the output **IOLDB**. This is a collection of all configured masters and if they are connected the diagnostic process data associated with them.

NotConnectedErrorFlag

This Boolean is connected to the HMI monitoring area for alarm messages to be displayed by the HMI alarm banner; It is true when a port is enabled, and configured but a device is not connected


ParamErrorFlag

This Boolean is connected to the HMI monitoring area for alarm messages to be displayed by the HMI alarm banner; It is true when a port has an error message

DeviceMismatchFlag

This Boolean is connected to the HMI monitoring area for alarm messages to be displayed by the HMI alarm banner. It is true when a connected device did not match the manufacturer and device ID configured on the HMI for that port.

3.4.2.3 IOLDiag_HMI FlowChart



3.5 IO-Link Device Process Data Function Blocks

There are eleven different types of process data function blocks available within the Balluff_IOL_Processdata

This section goes over how each type is used, and how to configure within your project.

3.5.1 Balluff Pressure Switch: Balluff_PSW_Processdata

Purpose: For each Balluff pressure switch used in a configuration, one instance of the **Balluff_PSW_Processdata** FB is recommended. For each instance of this FB, a new system label is required for each instance.

User Configuration:

Adding a new System label for each pressure switch that will be configured (Note: the target project must be part of a Melsoft Navigator project for the system label to function properly)

Setting the correct Port Number


Setting the correct MasterData(IOLDB) Instance

Setting the warning percentage range

Tying flag outputs to the HMI alarming section

3.5.1.1 System Label


1. Open the **IOLink** label group in the **Global Label** section of the target project:




2. On a blank row create a new tag with a **Class** of **VAR_GLOBAL** and any **Label Name** that fits your particular system:

13	VAR_GLOBAL	IOLinkPressureSwitch1	IOL_PressSwitch_ProcData	...
14	VAR_GLOBAL	IOLinkPressureSwitch2B		...
15	VAR_GLOBAL	AxisData	MELPT App AxisData(1..16)	...


3. For the **Data Type**, click the **Ellipse** Button. On the **Data Type Selection** screen, switch the **Type Class** to **Structured Data Types** and select **IOLink_PressSwitch_Data** as the **Data Type**:



4. Click **OK**.
5. On the lower right of the Global Label list window, click the **Reservation to Register System Label** button:




6. The **Reflect to System Label Database** will enable. Click it to register the label to Melssoft navigator:



7. Click **Yes** when prompted.
8. Click the **Register** button on the **Check before registering in system label database** window
9. Open the Melssoft Navigator project for this PLC project.
10. On the lower left of the Navigator window, an icon will be flashing red.
11. Right click it and click the **Change Contents of System Label Database** that appears:

Balluff IO-Link Profinet – Setup Guide




12. Click the **Import** button on the **Change Contents of System Label Database** window.
13. Open the GT Designer HMI project associate with this Navigator project.
14. Repeat steps 10-12 listed above in the HMI project.
15. Download the updated GT Designer 3 project to the HMI.

Adding a new Function Block for a pressure switch device:

1. Add an instance of the **Balluff_PSW_ProcessData** FB to the SCAN program. Configure these Input parameters and Output for **each** instance of the function block (see next page):

Use the System label created in the previous procedure.



3.5.1.2 Inputs

Input Name	Input Parameter Setting
i_eWarningThresholdPerc	Setpoint 1 is subtracted from Setpoint 2. This value is multiplied by the input percentage. The result is added to Set point 1, this creates the lower warning range. The result is also subtracted from setpoint2, this creates the upper warning range.
I_wPortNumber	This is a number 0-7 corresponding to the port the IO-link device is connected to on the master.
io_stMasterData	The data block for the master where this particular device is connected. This function block adjusts the return point parameters to one less than the set points

3.5.1.3 Outputs

Output Name	Output Description/Setting
o_bOK	This is True when the function block executes normally
o_bErr	This is True when the function block aborted execution due to error

o_uErrID	This is the Error code, when the function block aborted execution 256(0x100) Invalid Port Number 257(0x101) Invalid Device Type Detected 258(0x102) Device MisMatch 259(0x103) Device Not Connected
o_bPressureWarningFlag	When the Actual Value is within one of the warning ranges this output is true. It should be tied to the HMI alarming
o_bPressureErrorFlag	When the Actual Value is below Setpoint 1, or above SetPoint 2, this output is true. It should be tied to the HMI alarming.
o_stPressureSwitchData	This data structure contains all data for the HMI pertaining to this device

3.5.2 Balluff_Smartlight_ProcessData

Purpose: For each SmartLight used in a configuration, one instance of the **Balluff_SmartLight_Processdata** FB is recommended. For each instance of this FB, a new control label structure instance will be needed.

User Configuration:


Setting the correct Port Number

Setting the correct MasterData(IOLDB) Instance

Controlling the Data for the LightData Structure

Tying the Error Output to the HMI alarming system.

Tying the Output Data to the correct auto-refresh register.



3.5.2.1 Inputs

Input Name	Input Parameter Setting
i_stLightData	Data Structure used to control the output to the light
I_wMasterPort	This is a number 0-7 corresponding to the port the IO-link device is connected to on the master.
i_stMasterData	The data block for the master where this particular device is connected.

3.5.2.2 Outputs

Output Name	Output Description/Setting
o_bOK	This is True when the function block executes normally

o_bErr	This is True when the function block aborted execution due to error
o_uErrID	This is the Error code, when the function block aborted execution 256(0x100) Invalid Port Number 257(0x101) Invalid Device Type Detected 258(0x102) Invalid Mode Selected (more than one mode or no mode is selected)
o_bErrorDetected	The input data has an error code.
o_uOutputData	This is the starting register for the output telegram to the smartlight.

3.5.2.3 IOL_SmartLight_Data

1. IOL_SmartLight_Data

Label: LightData		
<u>Member</u>	<u>Type</u>	<u>Usage</u>
SegmentMode_Enabled	BOOL	True to Enable Segment Mode
SegMode_Segment1Color	WORD	0=off 1=green 2=red 3=yellow 4=blue 5=orange 6=user defined by parameter 7=white
SegMode_Segment1Blink	BOOL	TRUE=Blink
SegMode_Segment1Blink50	BOOL	When Blink ON Blink 50%

Balluff IO-Link Profinet – Setup Guide

Label: LightData		
Member	Type	Usage
SegMode_Segment2Color	WORD	0=off 1=green 2=red 3=yellow 4=blue 5=orange 6=user defined by parameter 7=white
SegMode_Segment2Blink	BOOL	TRUE=Blink
SegMode_Segment2Blink50	BOOL	When Blink ON Blink 50%
SegMode_Segment3Color	WORD	0=off 1=green 2=red 3=yellow 4=blue 5=orange 6=user defined by parameter 7=white
SegMode_Segment3Blink	BOOL	TRUE=Blink
SegMode_Segment3Blink50	BOOL	When Blink ON Blink 50%
SegMode_Segment4Color	WORD	0=off 1=green 2=red 3=yellow 4=blue 5=orange 6=user defined by parameter 7=white

Balluff IO-Link Profinet – Setup Guide

Label: LightData		
Member	Type	Usage
SegMode_Segment4Blink	BOOL	TRUE=Blink
SegMode_Segment4Blink50	BOOL	When Blink ON Blink 50%
SegMode_Segment5Color	WORD	0=off 1=green 2=red 3=yellow 4=blue 5=orange 6=user defined by parameter 7=white
SegMode_Segment5Blink	BOOL	TRUE=Blink
SegMode_Segment5Blink50	BOOL	When Blink ON Blink 50%
SegMode_NumberOfSegments	WORD	Number of Segments
SegMode_BlinkingFrequency	WORD	1=0.5hz 2=1hz 3=2HZ 4=5hz 5=10hz
LevelMode_Enabled	BOOL	True to Enable Level Mode

Balluff IO-Link Profinet – Setup Guide

Label: LightData		
Member	Type	Usage
LvlMode_Segment1Color	WORD	0=off 1=green 2=red 3=yellow 4=blue 5=orange 6=user defined by parameter 7=white
LvlMode_Segment1Dominance	BOOL	When true lower segments take this color
LvlMode_Segment2Color	WORD	0=off 1=green 2=red 3=yellow 4=blue 5=orange 6=user defined by parameter 7=white
LvlMode_Segment2Dominance	BOOL	When true lower segments take this color
LvlMode_Segment3Color	WORD	0=off 1=green 2=red 3=yellow 4=blue 5=orange 6=user defined by parameter 7=white

Balluff IO-Link Profinet – Setup Guide

Label: LightData		
Member	Type	Usage
LvlMode_Segment3Dominance	BOOL	When true lower segments take this color
LvlMode_Segment4Color	WORD	0=off 1=green 2=red 3=yellow 4=blue 5=orange 6=user defined by parameter 7=white
LvlMode_Segment4Dominance	BOOL	When true lower segments take this color
LvlMode_Segment5Color	WORD	0=off 1=green 2=red 3=yellow 4=blue 5=orange 6=user defined by parameter 7=white
LvlMode_Segment5Dominance	BOOL	When true lower segments take this color
LvlMode_LevelType	BOOL	True = Top Down
LvlMode_LevelValue	WORD	Value between 0-255
RunLight_Enabled	BOOL	True to Enable Run Light Mode

Balluff IO-Link Profinet – Setup Guide

Label: LightData		
Member	Type	Usage
RunLghtMode_BackGroundColor	WORD	0=off 1=green 2=red 3=yellow 4=blue 5=orange 6=user defined by parameter 7=white
RunLghtMode_RunningColor	WORD	0=off 1=green 2=red 3=yellow 4=blue 5=orange 6=user defined by parameter 7=white
RunLghtMode_NumberOfSegments	WORD	Value 1-5
RunLghtMode_RunningSpeed	WORD	Value 1-5
BuzzerState	BOOL	Buzzer On
BuzzerType	WORD	0=Continuous 1 1hz chopped 5 hz chopped 3=3 short beep with 2 sec pause

3.5.3 Balluff_BNI0041_ProcessData

Purpose:

This function block scales the input from the device and will output a value 4.0ms-20ma


For each Balluff Analog current input(BNI0041) used in a configuration, one instance of the **Balluff_BNI0041_Processdata** FB is recommended.

User Configuration:

Setting the correct Port Number

Setting the correct MasterData(IOLDB) Instance

Tying Current Error outputs to the HMI alarm monitoring



3.5.3.1 Inputs

Input Name	Input Parameter Setting
EN	Must be True for the function block to be executed
I_wMasterPort	This is a number 0-7 corresponding to the port the IO-link device is connected to on the master.
i_stMasterData	The data block for the master where this particular device is connected.

3.5.3.2 Outputs

Output Name	Output Description/Setting
o_bOK	This is True when the function block executes normally

o_bErr	This is True when the function block aborted execution due to error
o_uErrID	This is the Error code, when the function block aborted execution 256(0x100) Invalid Port Number 257(0x101) Device MisMatch 258(0x102) Device Not Connected
o_bErrorDetected	If the input to the device is below 4ma, the device will set an error output, that bool is reported here.
o_eInput_ma	The input data is scaled, a Value of 0.0 to 20.0 is output from this function block, if an error is occurring the output is 0.0

3.5.4 Balluff_BNI0042_ProcessData

Purpose:

This function block scales the input from the device and will output a value 4.0ms-20ma


For each Balluff Analog Voltage input used in a configuration, one instance of the

Balluff_BNI0042_Processdata FB is recommended.

User Configuration:

Setting the correct Port Number

Setting the correct MasterData(IOLDB) Instance



3.5.4.1 Inputs

Input Name	Input Parameter Setting
EN	Must be True for the function block to be executed
I_wMasterPort	This is a number 0-7 corresponding to the port the IO-link device is connected to on the master.
i_stMasterData	The data block for the master where this particular device is connected.

3.5.4.2 Outputs

Output Name	Output Description/Setting
o_bOK	This is True when the function block executes normally
o_bErr	This is True when the function block aborted execution due to error

o_uErrID	<p>This is the Error code, when the function block aborted execution</p> <p>256(0x100) Invalid Port Number</p> <p>257(0x101) Device MisMatch</p> <p>258(0x102) Device Not Connected</p>
o_eInput_V	<p>The input value is scaled and the function block will output a value between 0.0 and 10.0V</p>

3.5.5 Balluff_AnalogOut_ProcessData


Purpose:

This function block receives a user input between 0.0 and 100.0 the value is scaled and output to the device where the voltage or current is output.

For each Balluff Analog Output BNI004C or BNI004E used in a configuration, one instance of the **Balluff_AnalogOut_Processdata** FB is recommended.

User Configuration:

- Setting the correct Port Number
- Setting the correct MasterData(IOLDB) Instance
- Set a discrepancy timer value
- Control the Percentage Output Value
- Tie the auto-refresh register to the outputData
- Tie the EchoMismatchError to the HMI alarming



3.5.5.1 Inputs

Input Name	Input Parameter Setting
EN	Must be True for the function block to be executed
I_wMasterPort	This is a number 0-7 corresponding to the port the IO-link device is connected to on the master.
I_ePercentageOutput	A value between 0.0 and 100.0 corresponding to the percentage to be output.

I_stMasterData	The data block for the master where this particular device is connected.
I_tInputDiscrepancyTimer	The device echo's the value being output, internally the two are compared, if they do not match for the time input length, the echo mismatch error is TRUE

3.5.5.2 Outputs

Output Name	Output Description/Setting
o_bOK	This is True when the function block executes normally
o_bErr	This is True when the function block aborted execution due to error
o_uErrID	This is the Error code, when the function block aborted execution 256(0x100) Invalid Port Number 257(0x101) Device MisMatch 258(0x102) Device Not Connected
o_uOutputData	The percentage scaled and formatted for the device. Connect the auto-refresh register to this pin
o_uOutputDataEcho	The Data returned from the device
o_bEchoMisMatchError	When the Echo does not match the output data for the input discrepancy time.

3.5.6 Balluff_Ultrasonic_ProcessData


Purpose:

For each Balluff ultrasonic used in a configuration, one instance of the **Balluff_UltraSonic_Processdata** FB is recommended.

User Configuration:

Setting the correct Port Number

Setting the correct MasterData(IOLDB) Instance



3.5.6.1 Inputs

Input Name	Input Parameter Setting
EN	Must be True for the function block to be executed
I_wMasterPort	This is a number 0-7 corresponding to the port the IO-link device is connected to on the master.
io_stMasterData	The data block for the master where this particular device is connected. This function block will adjust the parameters to be within certain limits of the set points.

3.5.6.2 Outputs

Output Name	Output Description/Setting
o_bOK	This is True when the function block executes normally
o_bErr	This is True when the function block aborted execution due to error

o_uErrID	This is the Error code, when the function block aborted execution 256(0x100) Invalid Port Number 257(0x101) Device MisMatch 258(0x102) Device Not Connected
o_bOutputState	The Boolean State of the Switched Output
o_wDistanceValue_mm	The Data returned from the device scaled to mm

3.5.7 Balluff_BAW002F_ProcessData


Purpose:

For each Balluff BAW002F sensor used in a configuration, one instance of the **Balluff_BAW002F_Processdata** FB is recommended.

User Configuration:

Setting the correct Port Number

Setting the correct MasterData(IOLDB) Instance



3.5.7.1 Inputs

Input Name	Input Parameter Setting
EN	Must be True for the function block to be executed
i_wMasterPort	This is a number 0-7 corresponding to the port the IO-link device is connected to on the master.
i_stMasterData	The data block for the master where this particular device is connected. This function block will adjust the parameters to be within certain limits of the set points.

3.5.7.2 Outputs

Output Name	Output Description/Setting
o_bOK	This is True when the function block executes normally
o_bErr	This is True when the function block aborted execution due to error

o_uErrID	This is the Error code, when the function block aborted execution 256(0x100) Invalid Port Number 257(0x101) Device MisMatch
o_eDistanceValue_mm	The Data returned from the device scaled between 1.0 and 5.0 mm

3.5.8 Balluff_BIP0004_ProcessData


Purpose:

For each Balluff BIP0004 sensor used in a configuration, one instance of the **Balluff_BIP0004_Processdata** FB is recommended.

User Configuration:

Setting the correct Port Number

Setting the correct MasterData(IOLDB) Instance



3.5.8.1 Inputs

Input Name	Input Parameter Setting
EN	Must be True for the function block to be executed
I_wMasterPort	This is a number 0-7 corresponding to the port the IO-link device is connected to on the master.
i_stMasterData	The data block for the master where this particular device is connected. This function block will adjust the parameters to be within certain limits of the set points.

3.5.8.2 Outputs

Output Name	Output Description/Setting
o_bOK	This is True when the function block executes normally
o_bErr	This is True when the function block aborted execution due to error

o_uErrID	This is the Error code, when the function block aborted execution 256(0x100) Invalid Port Number 257(0x101) Device MisMatch
o_eDistanceValue_mm	The Data returned from the device scaled between 0.0 and 40.0 mm

3.5.9 Balluff_BOD0012_ProcessData

Purpose:

For each Balluff BOD0012 sensor used in a configuration, one instance of the **Balluff_BOD0012_Processdata** FB is recommended.


User Configuration:

Setting the correct Port Number

Setting the correct MasterData(IOLDB) Instance

Setting the output to sensor auto-refresh register

Turn in on the Laser to retrieve result



3.5.9.1 Inputs

Input Name	Input Parameter Setting
EN	Must be True for the function block to be executed
I_wMasterPort	This is a number 0-7 corresponding to the port the IO-link device is connected to on the master.
I_bLaserOn	Turns on Measurement
I_bButtonDisable	Disables user modification via sensor pushbutton

i_stMasterData	The data block for the master where this particular device is connected. This function block will adjust the parameters to be within certain limits of the set points.
-----------------------	--

3.5.9.2 Outputs

Output Name	Output Description/Setting
o_bOK	This is True when the function block executes normally
o_bErr	This is True when the function block aborted execution due to error
o_uErrID	This is the Error code, when the function block aborted execution 256(0x100) Invalid Port Number 257(0x101) Device MisMatch
O_uOutputToSensor	This is the output to the auto refresh register of the io-link device
o_uDistanceValue_mm	The Data returned from the device scaled between 0 and 6000
o_bSwitchPoint1Reached	Output when the distance exceeds switch point 1 parameter
o_bSwitchPoint2Reached	Output when the distance exceeds switch point 2 parameter
o_bSwitchPoint3Reached	Output when the distance exceeds switch point 3 parameter
o_bSwitchPoint4Reached	Output when the distance exceeds switch point 4 parameter
o_bSensorError	Output when the sensor reports error

3.5.10 Balluff_Valve16_ProcessData


Purpose:

For each 16 Valve Interface used in a configuration, one instance of the **Balluff_Valve16_Processdata** FB is recommended.

User Configuration:

Setting the output to valve interface auto-refresh register

Setting control bits for the individual valves



3.5.10.1 Inputs

Input Name	Input Parameter Setting
Valve_XX_Coil_A/B	Boolean Condition to output to an individual valve

3.5.10.2 Outputs

Output Name	Output Description/Setting
Output	This is the output to the auto refresh register of the io-link device

3.5.11Balluff_Valve24_ProcessData


Purpose:

For each 24 Valve Interface used in a configuration, one instance of the **Balluff_Valve24_Processdata** FB is recommended.

User Configuration:

Setting the output to valve interface auto-refresh register

Setting control bits for the individual valves



3.5.11.1 Inputs

Input Name	Input Parameter Setting
Valve_XX_Coil_A/B	Boolean Condition to output to an individual valve

3.5.11.2 *Outputs*

Output Name	Output Description/Setting
Output	This is the output to the auto refresh register of the io-link device

3.6 RFIDIF_Balluff_IOLink_256b / RFIDIF_BalluffBIS_V_M_2K

Purpose:

IO-link antennas can be used with the RFIDIF_Balluff_IOLink_256b function block. This function block allows for a continuous read/write of up to 256 bytes for one antenna.

When using the Balluff BIS-V or –M system.

You use the following function blocks:

RFIDIF_BalluffBIS_V_M_2K


This function block allows for a continuous read/write of up to 2048 bytes for one antenna.

User Configuration:

The user must place the correct Starting Input and Output auto-refresh registers

The user must configure the proper number of bytes per antenna (10 or 32 for IO-Link) Slot limited for BIS-V/M

RFID data is placed into a data structure with up to 16 elements. There is also a GOT RFID FB that control manual signals for this function block.



The RFID_Balluff User library contains programs, function blocks and SDT for use with the Balluff BIS-V, Balluff BIS-M, or Balluff IO-link RFID

If you are using the Balluff BIS-M RFID system the maximum size of an operation is 2000 bytes.

If you are using an IO-link antenna RFIDIF_Balluff_IOLink_256b must be used.

Balluff IO-Link Profinet – Setup Guide

FB Name

RFIDIF_BalluffBIS_V_M_2K

Item	Description
Function overview	This Function block handles manual and automatic RFID functions for 1 antenna of the system. Commands supported are: Read, Write, and Write Constant Value.
Symbol	<div style="display: flex; justify-content: space-between;"> <div style="width: 30%;"> <p>Input Pins</p> <p>Start of incoming RF Information</p> <p>Total Bytes (data +2)</p> <p>Perform Input Data evaluation</p> <p>Send Antenna to Ground state</p> <p>PreRequisite for Read</p> <p>Automatic Read Command</p> <p>PreRequisite for Write</p> <p>Automatic Write Command</p> <p>Set True to Write Constant</p> <p>Last Accessible Tag Address</p> <p>Auto Read Start Address</p> <p>Auto Write Length</p> <p>Auto Data to Write</p> </div> <div style="width: 40%; border: 1px solid black; padding: 5px;"> <p style="text-align: center;">RFIDIF_Balluff_IOLink(V_M)_2K)</p> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>i_uInputStartReg</p> <p>i_wBytesPerAntenna</p> <p>i_bFieldBusOK</p> <p>i_bFaultReset</p> <p>i_bReadCond</p> <p>i_bReadCmd</p> <p>i_bWriteCond</p> <p>i_bWriteCmd</p> <p>i_bTagClearOperation</p> <p>i_uLastTagByte</p> <p>i_uOperationStartAdd</p> <p>i_uOperationLengthBytes</p> <p>i_unWriteDataStart</p> </div> <div style="width: 45%;"> <p>o_bOK</p> <p>o_bERR</p> <p>o_uErrID</p> <p>o_uOutputStartReg</p> <p>o_wCurrentOpNumber</p> <p>o_wTotalOpNumber</p> <p>o_bAntennaReady</p> <p>o_bTagPresent</p> <p>o_bReadComplete</p> <p>o_bWriteComplete</p> <p>o_uErrorCode</p> <p>o_bFaultCmd</p> <p>o_bFaultTimeout</p> <p>o_unReadDataStart</p> </div> </div> </div> </div> <div style="width: 30%;"> <p>Output Pins</p> <p>Start of Outgoing RF Information</p> <p>Current Operation Cycle</p> <p>Operation Length/Bytes Per Operation</p> <p>Antenna Ready</p> <p>Tag Present</p> <p>Read Complete</p> <p>Write Complete</p> <p>Error Code</p> <p>RFID Controller Faulted</p> <p>RFID Controller No Response</p> <p>Auto Read Data</p> </div>

Balluff IO-Link Profinet – Setup Guide

Item	Description								
Applicable Software	<table border="1"> <thead> <tr> <th>Series</th><th>Version</th></tr> </thead> <tbody> <tr> <td>GX Works 2</td><td>1.540</td></tr> <tr> <td>GT Designer 3</td><td>1.136</td></tr> <tr> <td>Fieldbus Configurator</td><td></td></tr> </tbody> </table>	Series	Version	GX Works 2	1.540	GT Designer 3	1.136	Fieldbus Configurator	
Series	Version								
GX Works 2	1.540								
GT Designer 3	1.136								
Fieldbus Configurator									
Programming language	Structured Ladder/FBD								
Number of Ladder Steps	<p>QnU: 582 steps BIS_V_M</p> <p>QnU: 691 steps: IO-link</p> <p>*The number of steps of the FB program depends on the CPU Model that is used and input and output definition</p>								
Device Memory Used									
Compiling method	Macro type;								
Execution type	Real-time Execution								
Dependences	The RFID controller needs to have 2-byte headers enabled; BIS-M must have synchronization enabled.								
Function description	<p>This function blocks separates status data from the antenna interrogated and places into HMI labels.</p> <p>It also moves HMI input data to the manual related members of the RFID data structure of the selected antenna.</p>								

Balluff IO-Link Profinet – Setup Guide

Item	Description
Restrictions and precautions	

Item	Description
Timing chart	<p>Read - Tag Present</p> <p>Write - Tag Present</p> <p>When operation completes with error</p>

Balluff IO-Link Profinet – Setup Guide

Item	Description

FB Error Code

Error Code	Description
0	No Error.
H100(256)	Bytes Per Antenna is less than 2
H101(257)	Bytes per antenna > 1024/2048
H110(272)	Manual Length = 0
H111(273)	Manual Length Greater than 16
H112(274)	Manual Operation Exceeds Tag Capacity
H120(288)	Auto Read Length = 0
H121(289)	Auto Read Length >1024/2048
H122(290)	Read Operation Exceeds Tag Capacity
H130(304)	Auto Write Length = 0
H131(305)	Auto Write Length >1024/2048
H132(306)	Write Operation Exceeds Tag Capacity
H140(320)	Fieldbus OK not true

Labels

Input labels

User	Symbol Name	Var_Input name	Data Type	Setting range	Description
Input					

Balluff IO-Link Profinet – Setup Guide

User Input	Symbol Name	Var_Input name	Data Type	Setting range	Description
X	Start of incoming RF Information	i_uInputStartReg	Word[Unsigned]		Input from Fieldbus
X	Total Bytes (data +2)	i_wBytesPerAntenna	Word[Signed]	1 to 1024/2048	to fieldbus maximum
X	Perform Input Data evaluation	i_bFieldBusOK	Bit		Fieldbus Ok signal
	Send Antenna to Ground state	i_bFaultReset	Bit		Fault Reset Signal
X	Prerequisite for Read	i_bReadCond	Bit		Input Conditions for Read
X	Read Command	i_bReadCmd	Bit		Read Request
X	Prerequisite for Write	i_bWriteCond	Bit		Input Conditions for Write
X	Write Command	i_bWriteCmd	Bit		Write Begin
X	Set True to Write Constant	i_bTagClearOperation	Bit		If this is true the next write will be a tag clear operation
	Last Accessible Tag Address	i_uLastTagByte	Word[Unsigned]		Tag Size
X	Operation Start Address	i_uOperationStartAdd	Word[Unsigned]	0 to i_uTagByteCapacity	Starting tag Address

Balluff IO-Link Profinet – Setup Guide

User Input	Symbol Name	Var_Input name	Data Type	Setting range	Description
X	Operation Length	i_uOperationLengthBytes	Word[Unsigned]	1 to 2048/2000/256	Length in Bytes
X	Data to Write	i_uWriteDataStart	Word[Unsigned]		Packed Data for Writing to the Tag

■ Output labels

User Output	Symbol Name	Var_Output name	Data Type	Description
	FB Executed Normally	o_bOK	Bit	When TRUE, indicates processing has completed normally
	FB Execution Aborted	o_bERR	Bit	When TRUE, indicates an Error has occurred
	FB Error Code	o_uErrID	Word[Unsigned]	FB Error Code Output
X	Start of Outgoing RF Information	o_uOutputStartReg	Word[Unsigned]	Output to fieldbus
	Current Operation Cycle	o_wCurrentOpNumber	Word[Signed]	Current Operation Number
	Operation Length/Bytes Per Operation	o_wTotalOpNumber	Word[Signed]	Total Operations to Complete
	Antenna Ready	o_bAntennaReady	Bit	RFID Ready For new Command Signal
	Tag Present	o_bTagPresent	Bit	Tag Presence Signal

Balluff IO-Link Profinet – Setup Guide

User Output	Symbol Name	Var_Output name	Data Type	Description
	Read Complete	o_bReadComplete	Bit	Read Complete signal
	Write Complete	o_bWriteComplete	Bit	Write Complete signal
	Error Code	o_uErrorCode	Word[Unsigned]	Error Code
	RFID Controller Faulted	o_bFaultCmd	Bit	On When Controller Error Bit TRUE
	RFID Controller No Response	o_bFaultTimeout	Bit	Command execution time > 20 seconds
X	Read Data	o_uReadDataStart	Word[Unsigned]	Received Data(available at Read Complete

FB Version Upgrade History	
Version	Description
1.01	Initial Release
1.02	Clear Manual Read memory on status Change
1.12	Changed the Manual Read Structure Modified FB variables to use the standard specified in BCN-89000-0823-D
1.13	Added Clear Tag Function
1.20	Added FB Status Outputs
2.00A	Adopted BCN-89000-0969; Corrected Issue with Tag Clear WTOB; Removed 5 Read Write Option, added ob_suRFIDReady; Move to flexible sized input and output
2.10	Continuous Read/write supported
3.00	Tag Clear is integrated into Write

Balluff IO-Link Profinet – Setup Guide

3.01	Label Name Updates
3.02	Removed Fault Timer Input
3.03	Added 256 byte function limit added to packet offset; Introduced IO-link version

SDT Usage

RFIDData

Global Label: RFIDData		
Member	Type	Usage
RFIDCHReady	Bit	Populated by this FB when a new command can be accepted
ManualReadCondTrue	Bit	Populated by associated program code to allow a manual read command
ManualWriteCondTrue	Bit	Populated by associated program code to allow a manual write command
ReadComplete	Bit	Populated by this FB when done and held true until input condition is released
WriteComplete	Bit	Populated by this FB when done and held true until input condition is released
TagPresent	Bit	Populated by this FB
ReadPermission	Bit	User Populated needed by this function block to know when to accept A Read Command
ReadCmd	Bit	User Populated to execute an automatic Read Command; Associated code will populate for HMI driven

Balluff IO-Link Profinet – Setup Guide

Global Label: RFIDData		
Member	Type	Usage
WritePermission	Bit	User Populated needed by this function block to know when to accept A Write Command
WriteCmd	Bit	User Populated to execute an automatic Read Command; Associated program code will populate for HMI driven
ControllerFault	Bit	Attached to FB output pins Command Fault
TimeOutFault	Bit	Attached to FB output pins for Timeout or no response
ErrorCode	Word[Unsigned]	Error Code received from RF controller
Length	Word[Unsigned]	User Populated for automatic control, Associated program code will populate for HMI driven
StartAddress	Word[Unsigned]	User Populated for automatic control, Associated program code will populate for HMI driven

MELPT_APP_GOTRFID

System Label: GOTRFID		
Member	Type	Usage
StationDataRequest_PB	Bit	
StationDataRequestPre_PB	Bit	
ManualRead_PB	Bit	
ManualWrite1_PB	Bit	
ManualWrite16_PB	Bit	
OnLastAntenna	Bit	

Balluff IO-Link Profinet – Setup Guide

System Label: GOTRFID		
Member	Type	Usage
OnLastAddress	Bit	
TagPresent	Bit	
CHReady	Bit	
ReadCondTrue	Bit	
WriteCondTrue	Bit	
ManualReadRequest	Bit(1..16)	Antenna Element used to Trigger Manual Read
ManualWriteRequest	Bit(1..16)	Antenna Element used to Trigger Manual Write
SelectedAntennaNumber	Word[Signed]	
SelectedStatus	Word[Unsigned]	
TagSizeBytes	Word[Unsigned]	Used as input check to prevent operation over the limits of the tag
RFIDErrorCommentNumber	Word[Unsigned]	
ErrorCodes	Word[Unsigned](1..16)	
WriteData1Byte	Word[Unsigned]	
StartAddress	Word[Unsigned]	
WriteStartAddress	Word[Unsigned]	
HMIData	Word[Unsigned](0..15)	

Application Example

To utilize this function block the following inputs and outputs need to be adapted to the application:

I_uInputStartReg

This is the starting register for the fieldbus input for this antenna. You can find this information in the auto-refresh range for the fieldbus used.

For example we are to configure antenna #1 on Profinet this is slot 1 on the device the starting register is W2001

I_wBytesPerAntenna

This is the length of the fieldbus input, this variable is symmetrical. If you define 254 bytes for input it will also output 254 bytes, this information is contained within the fieldbus setup of the node.

I_bFaultReset

Turning this bit to true will send an output from the PLC to the antenna to drive the antenna to ground state.

I_bReadCond

Conditions to allow Read operation, must be true to allow read operation

I_bWriteCond

Conditions to allow Write operation, must be true to allow Write or Tag Clear operation

I_bTagClearOperation

Set to TRUE to make your write operation a tag clear operation, the data used to clear the tag is the first byte of i_unAutoWriteData

O_uOutputStartReg

This is the starting register for the PLC output to this antenna. You can find this information in the auto-

refresh range for the fieldbus used.

For example we are to configure antenna #1 on Profinet this is slot 1 on the device the starting register is W1001. The function block outputs data for the number of bytes list on i_wBytesPerAntenna

O_bFaultCMD

This is true when the controller has returned an error code investigate o_uErrorCode for ErrorCode

O_bFaultTimeout

3.6.1 MELPT_APP_RFIDGOT

This program calls the function block MELPT_APP_RFIDGOT_1KB, _2KB, or _256b. Only one of these programs is designed to be in the scan at any one time and is intended to be used with the data structures needed by the RFID system in use

FB Name

MELPT_APP_RFIDGOT

Item	Description																																																																																																																				
Function overview	This function block interfaces GOT related RFID functions to the selected RFID IF FB. 1 instance per GOT screen, this function block can interface with up to 16 antenna data structures.																																																																																																																				
Symbol	<table><thead><tr><th>Input Pins</th><th colspan="2">MELPT_APP_RFIDGOT</th><th>Output Pins</th></tr></thead><tbody><tr><td>Total Number of Antennas</td><td>i_wTotalAntennaNo</td><td>o_bOK</td><td></td></tr><tr><td>HMI Read PB</td><td>i_bRead_PB</td><td>o_bERR</td><td></td></tr><tr><td>HMI Write 16 bytes PB</td><td>i_bWrite16_PB</td><td>o_uErrID</td><td></td></tr><tr><td>HMI Write 1 PB</td><td>i_bWrite1_PB</td><td>o_bOnLastAntenna</td><td>HMI Cursor Control</td></tr><tr><td>Screen Active</td><td>i_bRFIDScreenActive</td><td>o_bOnLastAddress</td><td>HMI Cursor Control</td></tr><tr><td>1 byte Start Address</td><td>i_u1byteStartAddress</td><td>o_bReadCondTrue</td><td>HMI Read Permission</td></tr><tr><td>1 Byte Write Data</td><td>i_uEditWriteData</td><td>o_bWriteCondTrue</td><td>HMI Write Permission</td></tr><tr><td>Data Structure Antenna 1</td><td>i_stRFIDDATA_1</td><td>o_bTagPresent</td><td>Tag Present for Selected Antenna</td></tr><tr><td>Data Structure Antenna 2</td><td>i_stRFIDDATA_2</td><td>o_bChannelReady</td><td>Channel Ready for Selected Antenna</td></tr><tr><td>Data Structure Antenna 3</td><td>i_stRFIDDATA_3</td><td>o_bnManualRead</td><td>Manual Read Request to Antenna</td></tr><tr><td>Data Structure Antenna 4</td><td>i_stRFIDDATA_4</td><td>o_bnManualWrite</td><td>Manual Write Reques to Antenna</td></tr><tr><td>Data Structure Antenna 5</td><td>i_stRFIDDATA_5</td><td>o_uManualStartAddress</td><td>Manual location start address</td></tr><tr><td>Data Structure Antenna 6</td><td>i_stRFIDDATA_6</td><td>o_uManualLength</td><td>Manual Length</td></tr><tr><td>Data Structure Antenna 7</td><td>i_stRFIDDATA_7</td><td>o_uRFIDStatus</td><td>Rfid status for selected antenna</td></tr><tr><td>Data Structure Antenna 8</td><td>i_stRFIDDATA_8</td><td>o_uErrorCode</td><td>Error Code for all antenna</td></tr><tr><td>Data Structure Antenna 9</td><td>i_stRFIDDATA_9</td><td></td><td></td></tr><tr><td>Data Structure Antenna 10</td><td>i_stRFIDDATA_10</td><td></td><td></td></tr><tr><td>Data Structure Antenna 11</td><td>i_stRFIDDATA_11</td><td></td><td></td></tr><tr><td>Data Structure Antenna 12</td><td>i_stRFIDDATA_12</td><td></td><td></td></tr><tr><td>Data Structure Antenna 13</td><td>i_stRFIDDATA_13</td><td></td><td></td></tr><tr><td>Data Structure Antenna 14</td><td>i_stRFIDDATA_14</td><td></td><td></td></tr><tr><td>Data Structure Antenna 15</td><td>i_stRFIDDATA_15</td><td></td><td></td></tr><tr><td>Data Structure Antenna 16</td><td>i_stRFIDDATA_16</td><td></td><td></td></tr><tr><td>HMI Comment Number</td><td>io_uHMICommentNumber ...</td><td></td><td>HMI Comment Number</td></tr><tr><td>Selected Antenna</td><td>io_wSelectedAntenna ...</td><td>io_wSelectedAntenna</td><td>Selected Antenna</td></tr><tr><td>16 Byte Address</td><td>io_u16byteStartAddress ...</td><td>io_u16byteStartAddress</td><td>16 Byte Address</td></tr><tr><td>Maximum Number of Bytes</td><td>io_uTagMaxByte ...</td><td>io_uTagMaxByte</td><td>Maximum Number of Bytes</td></tr><tr><td>Manual RFID Data</td><td>io_unManualHMIRFIDData ...</td><td>io_unManualHMIRFIDData</td><td>Manual RFID Data</td></tr></tbody></table>	Input Pins	MELPT_APP_RFIDGOT		Output Pins	Total Number of Antennas	i_wTotalAntennaNo	o_bOK		HMI Read PB	i_bRead_PB	o_bERR		HMI Write 16 bytes PB	i_bWrite16_PB	o_uErrID		HMI Write 1 PB	i_bWrite1_PB	o_bOnLastAntenna	HMI Cursor Control	Screen Active	i_bRFIDScreenActive	o_bOnLastAddress	HMI Cursor Control	1 byte Start Address	i_u1byteStartAddress	o_bReadCondTrue	HMI Read Permission	1 Byte Write Data	i_uEditWriteData	o_bWriteCondTrue	HMI Write Permission	Data Structure Antenna 1	i_stRFIDDATA_1	o_bTagPresent	Tag Present for Selected Antenna	Data Structure Antenna 2	i_stRFIDDATA_2	o_bChannelReady	Channel Ready for Selected Antenna	Data Structure Antenna 3	i_stRFIDDATA_3	o_bnManualRead	Manual Read Request to Antenna	Data Structure Antenna 4	i_stRFIDDATA_4	o_bnManualWrite	Manual Write Reques to Antenna	Data Structure Antenna 5	i_stRFIDDATA_5	o_uManualStartAddress	Manual location start address	Data Structure Antenna 6	i_stRFIDDATA_6	o_uManualLength	Manual Length	Data Structure Antenna 7	i_stRFIDDATA_7	o_uRFIDStatus	Rfid status for selected antenna	Data Structure Antenna 8	i_stRFIDDATA_8	o_uErrorCode	Error Code for all antenna	Data Structure Antenna 9	i_stRFIDDATA_9			Data Structure Antenna 10	i_stRFIDDATA_10			Data Structure Antenna 11	i_stRFIDDATA_11			Data Structure Antenna 12	i_stRFIDDATA_12			Data Structure Antenna 13	i_stRFIDDATA_13			Data Structure Antenna 14	i_stRFIDDATA_14			Data Structure Antenna 15	i_stRFIDDATA_15			Data Structure Antenna 16	i_stRFIDDATA_16			HMI Comment Number	io_uHMICommentNumber ...		HMI Comment Number	Selected Antenna	io_wSelectedAntenna ...	io_wSelectedAntenna	Selected Antenna	16 Byte Address	io_u16byteStartAddress ...	io_u16byteStartAddress	16 Byte Address	Maximum Number of Bytes	io_uTagMaxByte ...	io_uTagMaxByte	Maximum Number of Bytes	Manual RFID Data	io_unManualHMIRFIDData ...	io_unManualHMIRFIDData	Manual RFID Data
Input Pins	MELPT_APP_RFIDGOT		Output Pins																																																																																																																		
Total Number of Antennas	i_wTotalAntennaNo	o_bOK																																																																																																																			
HMI Read PB	i_bRead_PB	o_bERR																																																																																																																			
HMI Write 16 bytes PB	i_bWrite16_PB	o_uErrID																																																																																																																			
HMI Write 1 PB	i_bWrite1_PB	o_bOnLastAntenna	HMI Cursor Control																																																																																																																		
Screen Active	i_bRFIDScreenActive	o_bOnLastAddress	HMI Cursor Control																																																																																																																		
1 byte Start Address	i_u1byteStartAddress	o_bReadCondTrue	HMI Read Permission																																																																																																																		
1 Byte Write Data	i_uEditWriteData	o_bWriteCondTrue	HMI Write Permission																																																																																																																		
Data Structure Antenna 1	i_stRFIDDATA_1	o_bTagPresent	Tag Present for Selected Antenna																																																																																																																		
Data Structure Antenna 2	i_stRFIDDATA_2	o_bChannelReady	Channel Ready for Selected Antenna																																																																																																																		
Data Structure Antenna 3	i_stRFIDDATA_3	o_bnManualRead	Manual Read Request to Antenna																																																																																																																		
Data Structure Antenna 4	i_stRFIDDATA_4	o_bnManualWrite	Manual Write Reques to Antenna																																																																																																																		
Data Structure Antenna 5	i_stRFIDDATA_5	o_uManualStartAddress	Manual location start address																																																																																																																		
Data Structure Antenna 6	i_stRFIDDATA_6	o_uManualLength	Manual Length																																																																																																																		
Data Structure Antenna 7	i_stRFIDDATA_7	o_uRFIDStatus	Rfid status for selected antenna																																																																																																																		
Data Structure Antenna 8	i_stRFIDDATA_8	o_uErrorCode	Error Code for all antenna																																																																																																																		
Data Structure Antenna 9	i_stRFIDDATA_9																																																																																																																				
Data Structure Antenna 10	i_stRFIDDATA_10																																																																																																																				
Data Structure Antenna 11	i_stRFIDDATA_11																																																																																																																				
Data Structure Antenna 12	i_stRFIDDATA_12																																																																																																																				
Data Structure Antenna 13	i_stRFIDDATA_13																																																																																																																				
Data Structure Antenna 14	i_stRFIDDATA_14																																																																																																																				
Data Structure Antenna 15	i_stRFIDDATA_15																																																																																																																				
Data Structure Antenna 16	i_stRFIDDATA_16																																																																																																																				
HMI Comment Number	io_uHMICommentNumber ...		HMI Comment Number																																																																																																																		
Selected Antenna	io_wSelectedAntenna ...	io_wSelectedAntenna	Selected Antenna																																																																																																																		
16 Byte Address	io_u16byteStartAddress ...	io_u16byteStartAddress	16 Byte Address																																																																																																																		
Maximum Number of Bytes	io_uTagMaxByte ...	io_uTagMaxByte	Maximum Number of Bytes																																																																																																																		
Manual RFID Data	io_unManualHMIRFIDData ...	io_unManualHMIRFIDData	Manual RFID Data																																																																																																																		

Balluff IO-Link Profinet – Setup Guide

Item	Description		
Applicable Hardware			
	Series	Model	Serial Restriction
	MELSEC-Q series	Universal Model PLC	None
	GOT 1000 series	GT16(800*600) or Higher	None
Applicable Software			
	Series	Version	
	GX Works 2	1.536	
	GT Designer 3	1.136	
Programming language	Structured Ladder/FBD		
Number of Ladder Steps	QnU: 1286 steps *The number of steps of the FB program depends on the CPU Model that is used and input and output definition		
Device Memory Used	MELPT_APP_RFIDGOT 61 bits 98 words		
Compiling method	Macro type;		
Execution type	Real-time Execution		
Dependences			
Function description	This function block multiplexes up to 16 antenna worth of information for display on the HMI. The status of the selected antenna is determined, and Manual RFID Read and Write Requests are generated from this FB.		

Balluff IO-Link Profinet – Setup Guide

Item	Description
Restrictions and precautions	
Timing chart	<div> <p>When operation completes without error</p> <p>When operation completes with error</p> </div>

FB Error Code

Error Code	Description
------------	-------------

Balluff IO-Link Profinet – Setup Guide

Error Code	Description
0	No Error.
H101(257)	Tag Max Byte is equal to zero
H102(258)	Total Antenna Number is greater than 16
H103(259)	Total Antenna number is less than or equal to zero

Labels

■ Input labels

User Input	Symbol Name	Var_Input name	Data Type	Setting range	Description
X	Total Number of Antennas	i_wTotalAntennaNo	Word[Signed]	1 to 16	No. of Antennas used
	HMI Read PB	i_bRead_PB	Bit		HMI PB to read tag
	HMI Write 16 bytes PB	i_bWrite16_PB	Bit		HMI PB to write to tag 16 bytes
	HMI Write 1 PB	i_bWrite1_PB	Bit		HMI PB to write to tag 1 byte
	Screen Active	i_bRFIDScreenActive	Bit		Screen Active Bit
	RFID IF Data Structure	i_stRFIDData_X	RFIDData_1KB RFIDData_2KB RFIDData_256b		RFID Data for one antenna
	1 byte Start Address	i_u1byteStartAddress	Word[Unsigned]		1 Byte Write Start Address
	1 Byte Write Data	i_uEditWriteData	Word[Unsigned]		The data to be written to the tag for 1-byte write

■ Input/Output labels

User Input	Name	Var_In_Out name	Data Type	Setting range	Description
---------------	------	-----------------	-----------	------------------	-------------

Balluff IO-Link Profinet – Setup Guide

User Input	Name	Var_In_Out name	Data Type	Setting range	Description
x	HMI Comment Number	io_uHMICommentNumber	Word[Unsigned]	1-255	Comment File for the Advanced user Alarm.
	Selected Antenna	io_wSelectedAntenna	Word[Signed]		Selected Antenna
	16 Byte Address	io_u16byteStartAddress	Word[Unsigned]		16 Byte Start Address
x	Maximum Number of Bytes	io_uTagMaxByte	Word[Unsigned]	0-32k	Tag Size in Bytes
	Manual RFID Data	io_unManualHMIRFIDData	Word[Unsigned](0..15)		16-byte write data or data read from tag

■ Output labels

Name	Var_Output name	Data Type	Description
FB Executed Normal	o_bOK	Bit	When TRUE, indicates processing has completed normally
FB Execution abnormal	o_bERR	Bit	When TRUE, indicates an Error has occurred
FB Error Code	o_uErrID	Word[Unsigned]	FB Error Code Output
HMI Cursor Control	o_bOnLastAntenna	Bit	HMI Indicator for PB Control
HMI Cursor Control	o_bOnLastAddress	Bit	HMI Indicator for PB Control
HMI Read Permission	o_bReadCondTrue	Bit	HMI Indicator for PB Control
HMI Write Permission	o_bWriteCondTrue	Bit	HMI Indicator for PB Control
Tag Present for Selected Antenna	o_bTagPresent	Bit	Tag present Ind. On HMI
Channel Ready for Selected Antenna	o_bChannelReady	Bit	Selected Antenna can accept new command
Manual Read Request to Antenna	o_bnManualRead	Bit(1..16)	Manual Read to RFID FB

Balluff IO-Link Profinet – Setup Guide

Name	Var_Output name	Data Type	Description
Manual Write Request to Antenna	o_bnManualWrite	Bit(1..16)	Manual Write to RFID FB
Manual location start address	o_uManualStartAddress	Word[Unsigned]	Manual Start Address
Manual Length	o_uManualLength	Word[Unsigned]	Manual Operation Length
RFID status for selected antenna	o_uRFIDStatus	Word[Unsigned]	Status of RFID HMI Ind.
Error Code for all antenna	o_uErrorCode	Word[Unsigned](1..16)	Array of Error Codes to Display on HMI

FB Version Upgrade History

Version	Description
1.10	Initial Release
1.12	Label Update
1.20	FB Status Outputs added
2.00A	Adopted BCN-89000-0969 added intelligent module check, changes made to screen display and use of Superimpose Offset; Issue with Detailed Diagnostic Output corrected
2.10	Start address changed to double word
3.00	Modified for version 3.00 structures, start address back to single word
3.03	Modified for 16 independent inputs instead of array of structures; memory improvement

SDT Usage

1. RFIDData

Balluff IO-Link Profinet – Setup Guide

Global Label: RFIDData		
Member	Type	Usage
RFIDCHReady	Bit	Selected Antenna Data forwarded to HMI structure
ManualReadCondTrue	Bit	Selected Antenna Data forwarded to HMI structure
ManualWriteCondTrue	Bit	Selected Antenna Data forwarded to HMI structure
ReadComplete	Bit	Selected Antenna Data forwarded to HMI structure
WriteComplete	Bit	Selected Antenna Data forwarded to HMI structure
TagPresent	Bit	Selected Antenna Data forwarded to HMI structure
ReadPermission	Bit	Selected Antenna Data forwarded to HMI structure
ReadCmd	Bit	
WritePermission	Bit	Selected Antenna Data forwarded to HMI structure
WriteCmd	Bit	
ErrorCode	Word[Unsigned]	All Data forwarded to HMI
Length	Word[Unsigned]	Modified by this FB and sent to individual RF function block
StartAddress	Word[Unsigned]	Modified by this FB and sent to individual RF function block

2. MELPT_APP_GOTRFID

System Label: GOTRFID		
Member	Type	Usage
StationDataRequest_PB	Bit	
StationDataRequestPre_PB	Bit	
ManualRead_PB	Bit	GOT Screen Manual Read
ManualWrite1_PB	Bit	GOT Screen Manual Write 1 byte
ManualWrite16_PB	Bit	GOT Screen Manual Write 16byte

Balluff IO-Link Profinet – Setup Guide

System Label: GOTRFID		
Member	Type	Usage
OnLastAntenna	Bit	True when on Last Antenna
OnLastAddress	Bit	True When on Last Address
TagPresent	Bit	Tag Present Ind.
CHReady	Bit	Antenna Ready Indicator
ReadCondTrue	Bit	Read Cond True allow Manual Read Push Button
WriteCondTrue	Bit	Write Cond True FB will accept Manual Write PB if pressed
ManualReadRequest	Bit(1..16)	Manual Read Pulse for Each Antenna, this function block pulses the selected antenna bit
ManualWriteRequest	Bit(1..16)	Manual Write Pulse for Each Antenna, this function block pulses the selected antenna biut
SelectedAntennaNumber	Word[Signed]	Antenna Selection number hmi controlled
SelectedStatus	Word[Unsigned]	Determined by this FB
TagSizeBytes	Word[Unsigned]	This is the last editable byte number of the tag, used for input checking
RFIDErrorCommentNumber	Word[Unsigned]	Populate as part of the RFID driver you are using:
ErrorCodes	Word[Unsigned](1..16)	Error Codes for RFID alarming
WriteData1Byte	Word[Unsigned]	1 Byte of Write Data
StartAddress	Word[Unsigned]	Manual Read and 16 Write Start Add.
WriteStartAddress	Word[Unsigned]	1 byte Write Start Address

Balluff IO-Link Profinet – Setup Guide

System Label: GOTRFID		
<u>Member</u>	<u>Type</u>	<u>Usage</u>
HMIData	Word[Unsigned](0..15)	Manual Data I/O 16bytes of read/write data
OperationAddress	Word[Unsigned]	The Tag Start Address for HMI requests
OperationLength	Word[Unsigned]	The Length in bytes for HMI requests

4 GTDESIGNER 3 HMI ELEMENTS

Much of the Profinet and IO-Link Diagnostics HMI functionality is pre-configured to allow diagnostics of Profinet and IO-Link Devices and Parameter Read/Write on the Maintenance section. However, some extra configuration of certain screen elements may be required based on network requirements.

The first section will show the Profinet Diagnostics


The second section will cover the IO-Link Diagnostics screens.

The third section will show the Maintenance parameter screens for initial IO-Link device parameter setup and subsequent adjustment of parameters.

The fourth section will cover what is needed to add the pressure switch graphics to an HMI screen.

The fifth section regards the Manual Edit Screen for RFID.

Script Symbols are used, the proper devices on the PLC must be assigned to the Script Symbol












4.1.1 ProfiNet Diagnostic Displays

Fieldbus Diagnostics will determine fieldbus node health.

The associated function block will determine node health and categorize the node number into one of the following categories


ProfinetDiag.Nodestatus[0..127]

State	Decimal Value	Graphic
Not Configured	0	
Normal	1	
Maintenance	34	
Ok Was Maintained	33	
Defective	68	
Ok Was Defective	65	
Disconnected	136	
Ok Was Disconnected	129	
Deactivated	272	
Ok Was Deactivated	257	

Balluff IO-Link Profinet – Setup Guide

Each Fieldbus Diagnostic Screen can be broken into a layout and detailed diagnostic screen.

The layout is intended to give the operator a general view of machine operation, and where the fieldbus nodes are located.



Balluff IO-Link Profinet – Setup Guide

The detailed diagnostic is intended to provide detailed information about one node.

CONTINUOUS AUTO CYCLE	NO MODE	HOME	WORK COMPLETED	PROFINET DIAGNOSTIC		STATION ABCDEFGH I J DESCRIPT ABCDEFGH I J K L M N O P USER ABCDEFGH VERSION ABCDEFGH I J K L M N O P Q R S T U V W X	SCREEN 1: 3456 2: 23456 3: 23456 3456ms 3456ms	02/26/16 13:30:04	
Power Off Condition 1				02/26/16 13:30:04					
PROFINET RUN		OCCURRED		COMMENT		REST.			
MODULE OK		02/26/16 13:30		MAC Address Check Fails		13:30			
		02/26/16 13:30		MAC file encrypted not found		13:30			
		02/26/16 13:30		Assert		13:30			
		02/26/16 13:30		Error System		13:30			
UP	DOWN	COPY TO USB							UPDATE 7
DEVICE NUMBER		1		3		DEVICE ERROR		1	
STATION STATUS		MAINTENANCE		1) The IO-device produces in stop mode					NODE SELECT + 8
MANUFACTURER ID		E240		ORDER NUMBER		BN1005R			NODE SELECT - 9
MAC ADDRESS		00:00:12:34:EF:55		DEVICE NAME		Balluff IO			DEACTIVATE
IP-ADDRESS		192.168.001.001				Profinet Unknown Location 000			RESET STATUS 10
SUBNET MASK		255.255.255.000				Profinet Unknown Manufacturer 000			
GATEWAY		192.168.001.254							
SLOT NUMBER		1		MODULE STATUS		6			
MODULE IDENT NUM.		0		SUBMODULE STATUS		0			
SUBSLOT NUMBER		1							
SUBMODULE IDENT NUM		0							
CHANNEL NUMBER		2		CHANNEL ERROR		6 Short Circuit			
PROMPT 1				02/26/16 13:30:04					
MAIN	DIAGNOSTIC	CC-LINK IE LAYOUT	PROFINET LAYOUT	CC-LINK LAYOUT	PROFIBUS LAYOUT	FIELDBUS DETAILED DIAGNOSTIC		PROFIBUS DIAGNOSTIC REPEATER	

Screen script #300 monitors the screen you are on and when you are on a specific fieldbus diagnostic screen the specific labels associated with the screen are loaded into the general HMI registers for display.

Each Indicator on the Overview screen is layered with a hidden multifunction switch.

The switch accomplishes 3 tasks

Sets bit GB65111, when this bit is set the screen navigates to the appropriate detailed diagnostic screen

Sets the node number

When on the detailed diagnostic screen the information displayed is for this node number

Sets the particular fieldbus.update signal

This signal is used by the associated FB to know to retrieve information for the node selected

On each layout screen indicators and switches are provided for the maximum allowed nodes per fieldbus, it is recommended that not configured indicators be moved to another window inside the project for future use.


Navigation

The navigation bar has two options for each fieldbus

Layout





Detailed Diagnostic



The fieldbus detailed diagnostic button is a toggle switch to switch between the layout and detailed diagnostic for the selected Fieldbus

Balluff IO-Link Profinet – Setup Guide

Item #	Description	Object	Details	
	Module Faulted Indicator	Bit Lamp: ProfinetDiag.FieldbusModuleFault	Off	
			On	
2	Alarm Area	User Alarm Display(21)	COPY to USB button Executes Screen script that will copy alarms to E:\backup\Profinet.CSV	
3	Selected Node	Numeric Input ProfinetDiag.SelectedNode	Numeric Input limited by the first and last node number detected by FB; Sets ProfinetDiag.Update when a new value is entered	

Balluff IO-Link Profinet – Setup Guide

Item #	Description	Object	Details		
3	Selected	Word Lamp:	State	Value	Graphic
	Status	ProfinetDiag.SelectedStatus	Not Configured	0	NOT CONFIGURED
			Ok	1	OK
			Ok Was Maintained	33	OK, WAS MAINTAINED
			Maintenance	34	MAINTENANCE
			Ok Was Defective	65	OK, WAS DEFECTIVE
			Defective	68	DEFECTIVE
			Ok Was Disconnected	129	OK, WAS DISCONNECT
			Disconnected	136	DISCONNECTED
			Ok Was Deactivated	257	OK, WAS DEACTIVATE
			Deactivated	272	DEACTIVATED

Balluff IO-Link Profinet – Setup Guide

Item #	Description	Object	Details	
4	Device Error Code	Word Comment Display: Numeric Display: ProfinetDiag.SelectedDevice Diagnostic	Comment File #21 Device Error Text Turns yellow when not equal to zero <div style="border: 1px solid black; background-color: yellow; padding: 2px; display: inline-block;">DEVICE ERROR</div>	
5	Device Details	Information retrieved from device via acyclic means when the Profinet.update is triggered	Manufacturer ID	Retrieved by I&m0 ProfinetDiag.ManufacturerID
			Mac Address	Response to index F841 ProfinetDiag.MacAddress[0..2]
			IP Address	Response to index F841 ProfinetDiag.IPAddress[0..2]

Balluff IO-Link Profinet – Setup Guide

			Subnet Mask		Response to index F841 ProfinetDiag.SubnetMask[0..2]	
			Gateway		Response to index F841 ProfinetDiag.GatewayAddress[0..2]	
			Order Number		Retrieved by I&m0	
			Device Name		Response to index F841 ProfinetDiag.ChasisData[0..15]	
5	Location	Word Comment Display: ProfinetDiag.SelectedNode	Comment File #21 \$\$ + 10000			
	Manufacturer	Word Comment Display: ProfinetDiag.SelectedNode	Comment File #21 20000 + \$\$			
6	Channel Diagnostics	Information retrieved from device via acyclic means when the Profinet.update is triggered	Slot Number	Numeric Display	ProfinetDiag.Slot	
			Module Identifier Number	Numeric Display	ProfinetDiag.SlotIdent	
			Module Status	ProfinetDiag.SlotStatus	0	No Module
					1	Wrong Module
					2	Right Module
					3	Substitute Module
			SubSlot Number	Numeric Display	ProfinetDiag.SubSlot	

Balluff IO-Link Profinet – Setup Guide

			Submodule Identifier Number	Numeric Display	ProfinetDiag.SubSlotIDent	
			Submodule Status	Profinet Diag.SubSlotStatus	0	No submodule
					1	Wrong Submodule
					2	Locked by IO Controller
					4	Application Ready Pending
					7	Substitute
					Hex 8000-8007	Take Over Not Allowed
					Hex 8020-8040	Maintenance Required
					Hex 8040-8080	Maintenance Demanded
					Hex 8080-8100	Diagnosis Data
					Hex 8100-8110	Application ready Pending

Balluff IO-Link Profinet – Setup Guide

					Hex 8110- 8200	SUPERORDINATED LOCKED
					Hex 8000	OKAY
					Hex 9000- 9880	Substitute
					Hex 9800- 9A00	wrong
					Hex A000- FFFF	No submodule
			Channel Number	Numeric display	ProfinetDiag.ChannelNumber	
			Channel Error	Profinet Diag.Ch annelErr or	1	Short Circuit
					2	Under voltage
					3	Overvoltage
					4	Overload
					5	Over temperature
					6	Line Break
					7	Upper Limit Value Exceeded

Balluff IO-Link Profinet – Setup Guide


					8	Lower Limit Value Exceeded
					9	Error
					16	Parametrization Fault
					17	Power Supply Fault
					18	Fuse Blown / Open
					19	Communication Error
					20	Ground Fault
					21	Reference Point Lost
					22	Process Event Lost
					23	Threshold Warning
					24	Output Disabled
					25	Safety Event
					26	External Fault
					27	Sensor has incorrect Configuration
					28	Manufacturer Specific
					29	Primary Variable out of limits
					30	Non-primary Variable out of limits
					31	The Channel Needs Parameters
					32	Reserved
					33	Sensor Supply Short Circuit

Balluff IO-Link Profinet – Setup Guide

					34	Ground fault
7	Update Button	Bit Momentary Switch ProfinetDiag.Update	Refreshed all acyclic retrieved data and channel diagnostics.			
8	Node Select Buttons	Word Switch: ProfinetDiag.SelectedNode	Increment or decrements by 1 the Selected Node			
9	Deactivate /Activate PB	Bit Momentary Switch: ProfinetDiag.ActivateDeactivate_P B ProfinetDiag.ActiveNode_Ind	Toggles the Deactivated State of the Selected Node, this occurs while the system continues to run.			
10	Reset Status	Bit Momentary Switch: ProfinetDiag.ResetStatus	Places zero into ProfinetDiag.NodeStatus[SelectedNode]			

4.1.2 IO-Link Diagnostics

The IO-link Diagnostics Screen shows the Profinet Master Node device (on left) and the selected port's IO-Link connected io-link device on the right. See graphic below for more details:



IO-Link Diagnostic screen under normal operation.

See next page for IOL Diagnostic Faulted example.

Balluff IO-Link Profinet – Setup Guide

The screenshot displays the 'IO-LINK DIAGNOSTIC' screen. At the top, status bars show 'NO CYCLE', 'NO MODE', 'HOME', and 'WORK COMPLETED'. The main header includes 'IO-LINK DIAGNOSTIC' and system information: 'STATION: MELPT_DEMO', 'DESCRIPT: Demo Station', 'VERSION: MELPT_V300', 'USER: BALLUFF', 'SCREEN: 301 2101 3456', and a timestamp '11/12/2015 18:38:46'. Below this, 'Power Off Condition 1' is indicated. The interface is divided into sections: 'SELECTED I/O MASTER' (ADDRESS: 15), 'SELECTED PORT' (PORT: 5), and a 'PORTS' grid (Port0 to Port7). A red box labeled 'IOL Hub Device Fault' is shown on the left. The 'PORTS' grid shows Port 5 with a red indicator. A legend on the right explains the indicators: 'No Config, No Comm' (grey), 'Master Comm OK, Aux Power OK, IOL Port OK' (green), 'IOL Hub Normal Comm, IOL Master Port No Comm' (green), 'Master Fault, Pin 4/2 Short Circuit to 0 V' (red), 'Comm Fault, Sensor Short Circuit, IOL Hub Fault' (red), and 'Warning: Pin 4/2 Short Circuit to +24V' (yellow). A 'PROMPT 1' section at the bottom has buttons for 'MAIN', 'DIAGNOSTIC', and 'PREVIOUS SCREEN'. Red callout boxes provide additional context: 'Errors/Warnings from the Master Node device will have a solid red indicator. IO-Link Hub-related errors/warnings will be blinking', 'Any IO-Link hub faults will show a blinking red indicator on the Port button. Pressing this will show the faulted device on the right', 'Each IO-Link Hub device fault LEDs are replicated from the actual device.', and 'This legend can be used to determine the error or warning to aid in troubleshooting'.

Errors/Warnings from the Master Node device will have a solid red indicator. IO-Link Hub-related errors/warnings will be blinking

Any IO-Link hub faults will show a blinking red indicator on the Port button. Pressing this will show the faulted device on the right

Each IO-Link Hub device fault LEDs are replicated from the actual device.

This legend can be used to determine the error or warning to aid in troubleshooting

IO-Link Diagnostic screen with IO-Link Hub Fault.


4.1.3 IO-Link Maintenance – Device Parameters Setup Display

In the Maintenance section of the HMI, there is an IO-Link Maintenance screen which allows reading/writing of Parameters of All IO-Link Hubs of all IO-Link-enabled Node devices on a ProfiNet network.

The parameters for all the configured IOL hubs are stored in permanent memory in the PLC. Whenever a node is disconnected and reconnected or someone performs a Write Parameters function, data stored from that PLC memory location is written to the parameters of the target IO-Link hub device.

For initial commissioning of the ProfiNet network, all configured IO-Link devices must have Device Type assigned. This is accomplished by placing the device CFG function block in the initial scan. This will allow a check to be performed and annunciate a possible wrong device replacement/installation.

See below for more details:



All possible nodes on the ProfiNet network will have an enabled button here. Red-colored buttons represent some error on that node. Pressing the node button will load the node


Selected Port will highlight in blue . Enable/Disable is for IO-Link Diagnostics. Disabling for a port will prevent Errors/Warnings on the IO-Link device from registering as ProfiNet faults

Any port with a connected device type will show the device type name in this box. If communication is lost, the indicator will blink red.

IOL Parameter write error(s) will make the target node button blink red, pressing the button will load up error details to the right of the module graphic


Device mismatches will turn this indicator background red. White=device match.

Balluff IO-Link Profinet – Setup Guide



Any discovered IO-Link device product IDs that do not match the user-configured model type will show in red. When setup is first done, use the legend provided on the screen to set the device to the proper model type.

1.B1S00LH	RFID Antenna	6.ENI003A	M12 Input/Output Hub
2.ENI0087	Smart Light 1 Seg w/Buzz	7.BIP0004	Linear Pos. System
3.ENI0085	Smart Light 5 Seg w/Buzz	8.BAW002F	Inductive Pos. System
4.ENI0022	M8 Input Hub	9.BOD0012	Laser Distance Sensor
5.ENI0039	M12 Input Hub	10.BUS004Z	UltraSonic 350mm



Actual parameter settings for IO-Link device are listed here. Use the Scroll Down and Scroll Up buttons to view next 5 or previous 5 parameters (32 total parameters possible).

If an Error occurred during a parameter write the error information is displayed here:


Press Either the Decimal (DEC) value or Hexadecimal (HEX) value for each parameter to input new values, Clicking Enter on the number display when complete.

When the Enter key is pressed for numeric entry the parameters are saved to the PLC. If it is connected, a 10 second timer begins additional edits can be made, to reset the timer. Parameters are written to the device when the timer expires, the device is navigated away from, or the write Parameters Push Button is pressed.

4.1.4 IO-Link Pressure Switch Devices

4.1.4.1 Modifying Set points


When modifying the setpoint of a Balluff pressure switch, the pressure switch accepts the parameter in bar, with a device multiplier. The operator may not know the conversion to the unit type commonly used. On the maintenance screen when a pressure switch device is selected the Pressure Sw. Setpoint Edit button is available.



This window converts the current parameter value into the current unit type. When a change is to be made the operator will place a new value in the input box, the parameter value is calculated in the display box. Transferring from the window to the parameter list is done with the copy to push button.


4.1.4.2 Graphics Display

The Balluff pressure switch IO-Link device has a gauge window that can be added as an overlay window on any base HMI screen. For each pressure switch used on the system, a new duplicated gauge window must be created.




For each new pressure switch gauge needed, window screen 32500 can be copied and pasted to new window screens (see next page):

After the copy/paste of the 32500 window screen, a new window dialog box appears. Adjust the Screen No. to any unused screen number and click OK. The



After Copying the Pressure Device window, use the Device Batch Edit top change HMI variables to the new system label.



BAR Color designations:

- RED: Less than SP1
- YELLOW: Between SP1 and $((SP2-SP1) \times 0.05) + SP1$
- GREEN: Between $((SP2-SP1) \times 0.05) + SP1$ and $SP2 - ((SP2-SP1) \times 0.05)$
- YELLOW: Between $SP2 - ((SP2-SP1) \times 0.05)$ and SP2
- RED: Greater than SP2

4.1.5 RFID Editing Screen

The RFID screen provides a manual interface to the RFID system installed

RFID systems are installed as a user library, the user library contains a program and function block for reading and writing to multiple antennas on a RFID controller.

The HMI Interface is a standard screen with HMI Interface function block. The program included in the user library already interfaces the HMI driven manual components with the standard RFID function block

Up to 16 antennas can be managed by the screen, function block and labels provided with MELPT

Writing to the RF tag is a password protected function

The screenshot shows the 'RFID EDITING' screen. At the top, there are status bars for 'NO CYCLE', 'NO MODE', 'HOME', 'WORK COMPLETED', and 'RFID EDITING'. To the right, system information is displayed: 'STATION STA-0500', 'SCREEN Base: 950', 'DESCRIPT Demo Station', 'USER L4', 'VERSION MELPT_V301', 'S1: 0', 'S2: 302', '20ms', '400ms', and the date/time '02/18/16 08:14:17'.

Below the status bars, there are four green bars with labels: 'ANTENNA 5' (1), 'READ COMPLETE' (2), 'ANTENNA READY' (3), and 'TAG PRESENT' (4). Below these is a 'FAULT MESSAGE' section with a 'RESTO' button (5).

The main area contains a '1-BYTE WRITE START' section (7) with 'DEC', 'HEX', and 'ASCII' input fields. Below this is a 'BYTE' field with a '12' value and an 'ENTER' button. To the right is a 'START ADDRESS' field with the value '32' (8).

In the center is a table with two columns of data. The first column has headers 'ADDR.', 'DEC', 'HEX', 'ASCII', and 'BINARY'. The second column has headers 'ADDR.', 'DEC', 'HEX', 'ASCII', and 'BINARY'. The table contains data for addresses 32 through 47.













On the right side, there are buttons for 'ANTENNA +', 'ANTENNA -', 'RFID READ' (9), 'ADDRESS +', 'ADDRESS -' (10), and 'WRITE' (11).

At the bottom, there is a 'MAIN' button and a 'RFID EDITING' button (13).

ADDR.	DEC	HEX	ASCII	BINARY	ADDR.	DEC	HEX	ASCII	BINARY
32	72	48	H	01001000	40	82	52	R	01010010
33	69	45	E	01000101	41	76	4C	L	01001100
34	76	4C	L	01001100	42	68	44	D	01000100
35	76	4C	L	01001100	43	0	0		00000000
36	79	4F	O	01001111	44	0	0		00000000
37	32	20		00100000	45	0	0		00000000
38	87	57	W	01010111	46	0	0		00000000
39	79	4F	O	01001111	47	0	0		00000000

Figure-RFID Editing Screen

Balluff IO-Link Profinet – Setup Guide

#	Description	Object	Details		
1	Antenna Number	Word Comment Display: GOTRFID.SelectedAntennaNumber Comment Displayed is \$\$+50 Comment File:125	1-16		
2	Operation Status Indicator	Word Comment Display: GOTRFID.SelectedStatus	Value	Graphic	
			None		
			1		
			2		
			3		
			4		
			5		
3	Antenna Status	Bit Lamp: GOTRFID.CHReady	State	Graphic	
			Off		
			On		
4	Tag Present	Word Lamp: 31 == GOTRFID.RFIDErrorCommentNumbe r GOTRFID.TagPresent	State	Graphic	
			None		
			31 == GOTRFID.RFIDError CommentNumber		
			GOTRFID.TagPresen t==0		
			GOTRFID.TagPresen t==1		

Balluff IO-Link Profinet – Setup Guide

#	Description	Object	Details
5	RFID Alarming	Advanced User Alarm Display(GOTRFID.RFIDErrorCommentNumber)	COPY to USB button Executes Screen script that will copy alarms to E:\backup\Balluff.CSV Or E:\backup\OMRON.CSV Based off value contained within PLC logic needs to place a value in GOTRFID.RFIDErrorCommentNumber
6	Antenna Selection PB	Word Switch:	Numeric Input limited to the maximum number of antenna
7	One Byte Write Address And Data	Accessible when GB65101 and GOTRFID.WriteCondTrue are TRUE Address: Numeric Input GOTRFID.WriteStartAddress Limited to $0 \leq \$W \leq \text{GOTRFID.TagSizeBytes}$	
8	16 Byte Start Address And Data	Numeric Input: GOTRFID.StartAddress Limited to $0 \leq \$W \leq \text{GOTRFID.TagSizeBytes}$	
9	RFID Read PB	Bit Momentary: GOTRFID.ManualRead_PB	GOTRFID.ReadCondTrue must be TRUE

Balluff IO-Link Profinet – Setup Guide

#	Description	Object	Details
10	Address Change PB	Word Switch: GOTRFID.StartAddress	Adds or Subtracts 16 to the Starting Address
11	RFID Write PB	Bit Momentary: GOTRFID.ManualWrite16_PB	GOTRFID.WriteCondTrue and GB65101 must be TRUE
12	Bit Enter	Byte: Bit Alternate GD64510.bit number Enter: Bit Set: GB64511	8 individual switched alternate the bits of a byte. Pressing the Enter Key executes a script that loads the value into GOTRFID.WriteData1Byte
13	Write 1-byte PB	Bit Momentary: GOTRFID.ManualWrite1_PB	

5 APPENIDX-CHANGE HISTORY

Beta Review:

Review Date:8/4/2015

First Demo, basic concept explained. Reading of parameters determined unnecessary

- Profinet V1.01

Review Date 9/30/2015

Modification from 5 devices to configurable 10 devices per PLC.

Profibus Version created from this version.

Pressure transducer Process FB introduced

- Profinet V1.02

Review Date 10/30/2015

Additional logic for fault detection and annunciation.

General bug fixes, added device configured logic, so data is not lost at power down.

Removal of the Initial device file, replaced by master functions.

Device Configured determination moved to GSDML function block

Pressure Transducer FB reworked

- Profinet V1.03
 - a. Device Access Lock Parameter added to pressure transducer parameter list and placed 1st
 - b. Default Parameter property introduced when device is configured default parameters are introduced
 - c. Lowering Rp1/Rp2, before setting SP additional parameters to the sequence
 - d. Added HMI Edit Inhibit boolean and scripting to disallow editing of certain parameters
 - e. Memory map modified to accomadate for 4-254 byte antennas
 - f. Added dual setpoint pressure transducer BSP008A
 - g. Increased font size and improved legend for diagnostics
 - h. General bug fixes
 - i. Number of Pages calculation or parameters

- Profinet V1.04

Modified Pressure Transducer function block,

- Profinet V2.00

CFG library is shared with Profinet release

Process library is shared with Profinet release

Added Configuration function blocks for all project book devices.

Created initial program to place configuration into data array.

Created Process Data function blocks for:

BIP0004

Analog

Valve

BAW002F

BOD0012

Smartlights

Revised network maintenance function blocks into single function block per master.

Revised HMI and parameter write function blocks for efficiency.

Standardized HMI FB between packages

HMI package migrated to GOT 2000

- Profinet V2.01 (7/26/2016)

Ultrasonic sensors were using an incorrect device type value. They are now type 8(.b3)

- Profinet V2.02 (8/10/2016)

- BNI0041 process data function block was improperly scaled
- RFID FB had not antenna faulted added to antenna ready status