

WSS and WS-V Series (50 – 630AF) UL489 Listed Internal Accessories

Circuit Breaker Series		Pole Installation	AL	AX	AL + AX	SHT	UVTN	UVTS
NFB	NV							
NF50-SVFU	-	Right Hand Pole	AL-03SVU	AX-03SVU	ALAX-03SVU	SHTA240-03SVUR SHTA440-03SVUR SHTD100-03SVUR	-	-
			AL-03SVURS	AX-03SVURS	ALAX-03SVURS	SHTA240-03SVURS SHTA440-03SVURS SHTD100-03SVURS	-	-
-	NV50-SVFU	Flying Type Lead	AL-03SVU	AX-03SVU	ALAX-03SVU	SHTA240-03SVUL SHTA440-03SVUL SHTD100-03SVUL	-	-
		Left Hand Pole	AL-03SVULS	AX-03SVULS	ALAX-03SVULS	SHTA240-03SVULS SHTA440-03SVULS SHTD100-03SVULS	-	-
NF100-SRU NF100-HRU	-	Right Hand Pole	AL-05SRU	AX-05SRU	ALAX-05SRU	SHTA240-05SRUR SHTA480-05SRUR SHTD125-05SRUR	-	-
			AL-05SRURS	AX-05SRURS	ALAX-05SRURS	SHTA240-05SRURS SHTA480-05SRURS SHTD125-05SRURS	-	-
-	NV100-SRU NV100-HRU	Flying Type Lead	AL-05SRU	AX-05SRU	ALAX-05SRU	SHTA110-05SRULS SHTA127-05SRULS SHTA220-05SRULS SHTA240-05SRULS SHTA415-05SRULS SHTA440-05SRULS SHTD024-05SRULS SHTD110-05SRULS	UVTNA110-05SRULS UVTNA127-05SRULS UVTNA220-05SRULS UVTNA240-05SRULS UVTNA415-05SRULS UVTNA440-05SRULS UVTND024-05SRULS UVTND110-05SRULS	-
		Left Hand Pole	AL-05SRULS	AX-05SRULS	ALAX-05SRULS			-
NF100-CVFU NF125-SVU/HVU NF250-SVU/HVU	-	Right Hand Pole	AL-05SVU	AX-05SVU	ALAX-05SVU	SHTA240-05SVUR SHTA550-05SVUR SHTD125-05SVUR	UVTNAD130-05SVUR UVTNA250-05SVUR UVTNA480-05SVUR	UVTSAD130-05SVUR UVTSA250-05SVUR UVTSA480-05SVUR
			AL-05SVURS	AX-05SVURS	ALAX-05SVURS	SHTA240-05SVURS SHTA550-05SVURS SHTD125-05SVURS	UVTNAD130-05SVURS UVTNA250-05SVURS UVTNA480-05SVURS	UVTSAD130-05SVURS UVTSA250-05SVURS UVTSA480-05SVURS
-	NV100-CVFU NV125-SVU/HVU NV250-SVU/HVU	Flying Lead Type	AL-05SVU	AX-05SVU	ALAX-05SVU	SHTA240-05SVUL SHTA550-05SVUL SHTD125-05SVUL	UVTNAD130-05SVUL UVTNA250-05SVUL UVTNA480-05SVUL	UVTSAD130-05SVUL UVTSA250-05SVUL UVTSA480-05SVUL
		Left Hand Pole	AL-05SVULS	AX-05SVULS	ALAX-05SVULS	SHTA240-05SVULS SHTA550-05SVULS SHTD125-05SVULS	UVTNAD130-05SVULS UVTNA250-05SVULS UVTNA480-05SVULS	UVTSAD130-05SVULS UVTSA250-05SVULS UVTSA480-05SVULS
NF400-SWU NF400-HWU NF630-SWU NF630-HWU	-	Right Hand Pole	-	AX-4SWU	-	SHT-4SWU	-	-
			-	AX-4SWURS	-	SHT-4SWURS	-	-
-	NV400-SWU NV400-HWU	Flying Lead Type	AL-4SWUL	AX-4SWUL	ALAX-4SWUL	SHT-4SWU	-	-
		Left Hand Pole	AL-4SWULS	AX-4SWULS	ALAX-4SWULS	SHT-4SWULS	-	-

Note: See WS-V series catalog for complete details and specifications.